

# FRONT SUSPENSION

## CONTENTS

N02AA--

|  |           |  |           |
|--|-----------|--|-----------|
| <b>AXLE HUB AND FREE-WHEELING HUB</b> .....      | <b>18</b> | Sealant and Adhesive .....                                 | 7         |
| <b>DIFFERENTIAL CARRIER</b> .....                | <b>68</b> | Service Specifications .....                               | 5         |
| <b>DRIVE SHAFT</b> .....                         | <b>52</b> | Torque Specifications .....                                | 6         |
| <b>FRONT DIFFERENTIAL MOUNTING</b> .....         | <b>66</b> | <b>STABILIZER BAR</b> .....                                | <b>51</b> |
| <b>GENERAL INFORMATION</b> .....                 | <b>2</b>  | <b>TORSION BAR</b> .....                                   | <b>48</b> |
| <b>INNER SHAFT</b> .....                         | <b>62</b> | <b>TROUBLESHOOTING</b> .....                               | <b>11</b> |
| <b>KNUCKLE</b> .....                             | <b>44</b> | AUTOMATIC FREE WHEELING HUB .....                          | 11        |
| <b>LOWER ARM</b> .....                           | <b>40</b> | Does not lock  |           |
| Replacement of Lower Arm Bushing .....           | 42        | Locks but does not become free                             |           |
| Replacement of Lower Ball                        |           | Ratcheting readily occurs                                  |           |
| Joint Dust Cover .....                           | 42        | DIFFERENTIAL .....   | 12        |
| <b>SERVICE ADJUSTMENT PROCEDURES</b> .....       | <b>14</b> | Bearing noise while driving or coasting                    |           |
| Checking Drive Shaft End Play .....              | 16        | Constant noise   |           |
| Checking Front Axle Total Backlash .....         | 15        | Gear noise while coasting                                  |           |
| Checking Gear Oil Level .....                    | 16        | Gear noise while driving                                   |           |
| Inspection and Adjustment of Wheel               |           | Heat   |           |
| Alignment .....                                  | 14        | Noise while turning  |           |
| Replacement of Differential Carrier Oil Seal ... | 17        | Oil leakage  |           |
| <b>SHOCK ABSORBER AND UPPER ARM</b> .....        | <b>35</b> | DRIVE SHAFT, INNER SHAFT .....                             | 12        |
| Replacement of Upper Ball Joint .....            | 37        | Noise due to excessive play of wheel in                    |           |
| <b>SPECIAL TOOLS</b> .....                       | <b>8</b>  | turning direction  |           |
| <b>SPECIFICATIONS</b> .....                      | <b>4</b>  | Noise due to excessive wheel end play                      |           |
| General Specifications .....                     | 4         | Noise during wheel rotation                                |           |
| Lubricants .....                                 | 7         | MANUAL FREE WHEELING HUB,<br>FRONT AXLE HUB, KNUCKLE ..... | 11        |
|  |           | Noise due to excessive play of wheel in                    |           |
|  |           | turning direction  |           |
|  |           | Noise due to excessive wheel end play                      |           |

## GENERAL INFORMATION

N02BBAA



The front suspension is an independent suspension which is a combination of the double-wishbone and torsion bar spring.

The front axle assembly consists of a front differential, a housing tube, an inner shaft, drive shafts, etc.

For better serviceability of the differential, the spacer for backlash adjustment of the final drive gear is placed between the side bearing outer race and the gear carrier.

The double-offset-joint which can slide in the axial direction, is used at the differential carrier side; the Birfield joint, with large operation angle, is used at the axle hub side.

To reduce vibration, noise, and fuel consumption when 2WD is applied, manual or automatic free-wheeling hubs are equipped; in particular, the automatic one is an outstanding feature in that the driver can switch between "lock" and "free" without having to leave his seat.




## MANUAL FREE-WHEELING HUB OPERATION

N02BCAA

**Free State → Locked State**

When the control handle is set to the LOCK position, the follower moves along the oblique groove in the control handle and causes the clutch (which is always in mesh with the free-wheeling hub body) to engage the splines of the inner hub, thus coupling the free-wheeling hub body with the drive shaft.

**Locked State → Free State**

When the control handle is set to the FREE position, the follower moves along the oblique groove in the control handle and uses the tension spring to disengage the clutch from the splines of the inner hub, thus separating the free-wheeling hub body from the drive shaft.

**AUTOMATIC FREE-WHEELING HUB OPERATION**

N02BDAA

**Free State → Locked State**

When the transfer is shifted from 2WD to 4WD and driving is begun, rotation of the drive shaft is transmitted from the drive gear to the slide gear to the cam to retainer (A) to brake (A). When this happens, brake (A) is pressed against brake (B) by the function of the cam of retainer (A), and friction force is generated.

Because brake (B) is secured to the knuckle, retainer (A) ceases to rotate, and therefore, the cam, while compressing the return spring, rises out of the cam groove of the retainer (A) and compresses the shift spring. The slide gear is pushed by the shift spring, and then engages with the gear of the housing when the two are in phase and enters the locked state.


The cam turns until the lug of the drive gear contacts the lug of brake (A). Because of this contact, brake (A) is turned by the drive gear, and therefore, there is also no longer any force of retainer (A) with a tendency to turn brake (A). As a result, there is also no longer any force which presses brake (A) against brake (B) and the drive gear causes brake (A) to turn lightly. (there is no friction force).

Because the cam remains meshed, it turns until it contacts the lug of retainer (A), and is locked.

**Locked State → Free State**


When the transfer is shifted from 4WD to 2WD and the vehicle is driven in reverse, rotation of the gear of the body is transmitted from the slide gear to cam to retainer (A) to brake (A), but retainer (A) ceases to turn, just as when the shift is made from the free state to the locked state. The cam therefore, turns as far as the cam groove of retainer (A) and is pushed into the cam groove by the return spring.

The slide gear moves with the cam, disengages from the gear of the doby, and enters a free state.



11W045

11W043



11W023

11W044

## SPECIFICATIONS

## GENERAL SPECIFICATIONS

N02CA--

| Items  | Specifications   |
|--|--|
| Suspension system                            | Independent double wishbone with torsion bar and telescopic shock absorber |
| Kingpin inclination angle                    | 8°   |
| Torsion bar                                  |  |
| Length x O.D.     mm (in.)                   | 1,277.5 x 24.5 (50.295 x .965)   |
| Spring constant     N/mm (lbs./in.)          | 22 (123)   |
| Shock absorber                               |  |
| Type   | Hydraulic cylindrical double-acting type                                   |
| Maximum length     mm (in.)                  | 335 (13.19)  |
| Compressed length     mm (in.)               | 215 (8.46)   |
| Stroke     mm (in.)                          | 120 (4.72)   |
| Damping force [at 0.3m/sec. (.984 ft./sec.)] |  |
| Expansion     N (lbs.)                       | 1,940–2,560 (428–564)  |
| Contraction     N (lbs.)                     | 900–1,300 (198–287)  |
| Front axle hub bearing                       |  |
| Type   | Tapered roller bearing   |
| Dimensions (O.D. x I.D.)     mm (in.)        |  |
| Outer  | 73.431 x 45.242 (2.8910 x 1.7811)  |
| Inner  | 73.431 x 45.242 (2.8910 x 1.7811)  |
| Drive shaft                                  |  |
| Joint type     Outer                         | B.J. (Birfield Joint)  |
| Inner  | D.O.J. (Double Offset Joint)   |
| Length     Right     mm (in.)                | 267 (10.5)   |
| (Joint to joint)     Left     mm (in.)       | 294 (11.6)   |
| Inner shaft                                  |  |
| Shaft overall length     mm (in.)            | 432 (17.0)   |
| Bearing                                      |  |
| O.D. x I.D.     mm (in.)                     | 62 x 35 (2.44 x 1.38)  |
| Differential                                 |  |
| Final drive gear type                        | Hypoid gear  |
| Reduction ratio                              | 4.625  |
| Differential gear type                       | Straight bevel gear  |
| Number of teeth                              |  |
| Drive gear                                   | 37   |
| Drive pinion                                 | 8  |
| Side gear                                    | 14   |
| Pinion gear                                  | 10   |

SERVICE SPECIFICATIONS

N02CB--

| Items  | Specifications            |
|--|---------------------------|
| Standard values  |                           |
| Toe-in mm (in.)  | 2-9 (.08-.35)             |
| Camber   | 1° ± 30'                  |
| Caster   | 2°57' ± 30'               |
| Drive shaft end play mm (in.)                                    | 0.2-0.5 (.008-.020)       |
| Front hub turning resistance Ncm (in.lbs.)                       | 30-130 (2.6-11.3)         |
| [Spring scale reading] N (lbs.)                                  | 5-18 (1.1-4.0)            |
| Front hub play in the axial direction mm (in.)                   | 0.05 (.0020) or less      |
| Automatic free-wheeling hub                                      |                           |
| Brake contact surface height mm (in.)                            | 11.8-12.2 (.465-.480)     |
| Brake assembly thickness mm (in.)                                | 10.5 (.41)                |
| Upper ball joint starting torque Ncm (in.lbs)                    | 80-350 (7-30)             |
| Clearance between bump stopper and bump stopper bracket mm (in.) | 71 (2.80)                 |
| Shock absorber attaching dimension mm (in.)                      | 7-8 (.27-.31)             |
| Stabilizer attaching bolt end attaching dimension mm (in.)       | 6-8 (.24-.31)             |
| Anchor arm attaching dimension mm (in.)                          |                           |
| L.H.   | 135.2-143.2 (5.323-5.638) |
| R.H.   | 124.3-132.3 (4.894-5.210) |
| Setting of D.O.J. boot length mm (in.)                           | 77-83 (3.03-3.27)         |
| Differential   |                           |
| Final drive gear backlash mm (in.)                               | 0.11-0.16 (.0043-.0063)   |
| Differential gear backlash mm (in.)                              | 0-0.076 (0-.0030)         |
| Drive pinion rotation torque                                     |                           |
| with oil seal Nm (in.lbs.)                                       | 0.6-0.7 (5.2-6.1)         |
| without oil seal Nm (in.lbs.)                                    | 0.4-0.5 (3.5-4.3)         |
| Limits   |                           |
| Front axle total backlash mm (in.)                               | 14 (.55)                  |
| Automatic free-wheeling hub                                      |                           |
| Free-wheeling hub turning resistance Ncm (in.lbs.)               | 100 (8.7)                 |
| [Spring scale reading] N (lbs.)                                  | 14 (3.1)                  |
| Brake assembly thickness mm (in.)                                | 9.6 (.378)                |
| Return spring deterioration mm (in.)                             | 35 (1.38)                 |
| Shift spring deterioration mm (in.)                              | 30 (1.18)                 |
| Upper arm shaft starting torque Nm (ft.lbs.)                     |                           |
| [Spring scale reading] N (lbs.)                                  | 6.8 (1.5)                 |
| Lower ball joint end play mm (in.)                               | 0.5 (.020)                |
| Differential   |                           |
| Drive gear runout mm (in.)                                       | 0.05 (.0020)              |
| Differential gear backlash mm (in.)                              | 0.2 (.008)                |

## TORQUE SPECIFICATIONS

N02CC--

| Items  | Nm      | ft.lbs  |
|--|---------|---------|
| Automatic free-wheeling hub cover                          | 18-35   | 13-25   |
| Manual free-wheeling hub cover                             | 10-14   | 7-10    |
| Free wheeling hub body or drive flange                     | 50-60   | 36-43   |
| Front hub to brake disc                                    | 50-60   | 36-43   |
| Knuckle to front brake assembly                            | 80-100  | 58-72   |
| Upper arm shaft to crossmember                             | 100-120 | 72-87   |
| Rebound stopper to upper arm                               | 8-12    | 6-9     |
| Upper ball joint to knuckle                                | 60-90   | 43-65   |
| Front shock absorber to crossmember                        | 12-18   | 9-13    |
| Front shock absorber to lower arm                          | 15-22   | 11-16   |
| Lower ball joint to knuckle                                | 120-180 | 87-130  |
| Lower arm shaft  | 140-160 | 101-116 |
| Lower arm ball joint to lower arm                          | 54-75   | 39-54   |
| Bump stopper to lower arm                                  | 20-30   | 14-22   |
| Anchor arm B   | 95-120  | 69-87   |
| Anchor arm lock nut  | 40-50   | 29-36   |
| Stabilizer bar clamp A                                     | 8-12    | 6-9     |
| Knuckle to tie rod assembly                                | 45      | 33      |
| Right drive shaft to inner shaft                           | 50-60   | 36-43   |
| Left differential mounting bracket to differential carrier | 80-100  | 58-72   |
| Right differential mounting bracket to housing tube        | 80-100  | 58-72   |
| Differential mounting brackets to frame                    | 80-110  | 58-80   |
| Housing tube to differential carrier                       | 80-100  | 58-72   |
| Bracket to differential carrier                            | 80-110  | 58-80   |
| Front propeller shaft to differential carrier              | 50-60   | 36-43   |
| Front suspension crossmember mounting bolts                | 100-120 | 72-87   |
| Drain plug   | 60-70   | 43-51   |
| Filler plug  | 40-60   | 29-43   |
| Companion flange   | 160-220 | 116-159 |
| Cover  | 15-22   | 11-16   |
| Bearing cap  | 55-65   | 40-47   |
| Differential case to drive gear                            | 80-90   | 58-65   |
| Under skid plate to side frame                             | 18-25   | 13-18   |
| Under cover to frame                                       | 10-13   | 7-9     |
| Brake tube flare nut                                       | 13-17   | 9-12    |

**LUBRICANTS**

NO2CD--








| Items  | Specified lubricants   | Quantity                                      |
|--|--|---|
| Front axle gear oil<br>Front differential  | Hypoid gear oil<br>API classification GL-4 or higher<br>SAE viscosity No. 80 W, 90 | 1.10 lit.<br>(1.16 U.S. qts., 0.97 Imp. qts.) |
| Front axle hub bearing   | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| Oil seal lip   | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| Automatic free wheeling hub  | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| Manual free wheeling hub   | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| Upper and lower ball joints  | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| Torsion bar serrations, anchor arm<br>assembly serrations, anchor arm B<br>serrations, dust cover inside and<br>anchor bolt thread | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| Needle bearing   | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| Contact surface of knuckle and<br>spacer   | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| D.O.J. boot grease   | Repair kit grease  | 110 g (1.9 oz.)                               |
| B.J. boot grease   | Repair kit grease  | 110 g (1.9 oz.)                               |
| Housing tube dust seal lip   | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| Housing tube dust cover  | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |
| Companion flange contacting<br>surface of the washer   | Multipurpose grease<br>SAE J310, NLGI No. 2  | As required                                   |










**SEALANTS AND ADHESIVES**


| Items   | Specified sealants and adhesives             |
|---|--|
| Slot of the upper or lower ball joint                   | 3M ART Part No. 8663, No. 8661 or equivalent |
| Contact surface of free-wheeling hub and front axle hub | 3M ART Part No. 8661, No. 8663 or equivalent |
| Drive gear threaded hole                                | 3M Adhesive STUD LOCKING 4170 or equivalent  |
| Gasket  | 3M ART Part No. 8661, No. 8663 or equivalent |

SPECIAL TOOLS

N02DA--

| Tool (Number and name)  | Use   | Tool (Number and name)   | Use   |
|---|---|--|---|
| MB990241-01<br>Drive shaft attachment<br>MB990211-01<br>Sliding hammer<br> | Removal and insertion of inner shaft assembly   | MB990955-01<br>Oil seal installer<br>  | Pressing of front axle hub oil seal<br>Pressing of housing tube oil seal  |
| MB990925-01<br>Bearing and oil seal installer set<br>                      | Pressing of front axle hub bearing outer race<br>Pressing of drive pinion bearing outer race<br>Pressing of differential carrier oil seal   | MB990811-01<br>Sidebearing cup remover step plate<br>  | Disassembly and reassembly of automatic free-wheeling hub<br>Removal of side bearing inner race                 |
| MB990938-01<br>Handle<br>  | Pressing of front axle hub bearing outer race<br>Pressing of front axle hub oil seal<br>Pressing of knuckle needle bearing<br>Pressing of knuckle oil seal<br>Pressing of housing tube oil seal<br>Pressing of differential carrier oil seal<br>Pressing of drive pinion bearing outer race | MB990778-01<br>Ball joint remover<br><br><br>MB990799-01<br>Ball joint remover and installer A<br><br><br>MB990800-01<br>Ball joint remover and installer B<br><br><br>MB990840-01<br>Universal joint remover and installer<br> | Removal of knuckle<br>Disconnection of upper ball joint<br><br>Removal and installation of upper arm ball joint |
| MB990954-01<br>Lock nut wrench<br>                                       | Removal and adjustment of lock nut  | MB990809-01<br>Pitman arm puller<br>   | Removal of knuckle<br>Disconnection of lower ball joint   |

| Tool (Number and name)  | Use  | Tool (Number and name)   | Use  |
|---|--|--|--|
| MB990958-01<br>Torsion bar bushing remover and installer<br> | Removal and pressing of bushing A              | MD998348-01<br>Bearing separator<br>             | Removal and pressing of inner shaft bearing  |
| MB990883-01<br>Arbor<br>                                     | Removal and pressing of the bushing B          | MB990339-01<br>Pinion carrier bearing puller<br> | Removal of side bearing inner race<br>Removal of drive pinion front bearing inner race |
| MB990635-01<br>Steering linkage puller<br>                  | Removal of knuckle<br>Disconnection of tie rod | MIT303173<br>Insert<br>                         | Removal of side bearing inner race<br>Removal of drive pinion front bearing inner race |
| MB990956-01<br>Needle bearing installer<br>                | Pressing of knuckle needle bearing             | MIT44801<br>Collet set<br>                     | Removal of side bearing inner race<br>Removal of drive pinion front bearing inner race |
| MB990985-01<br>Oil seal installer<br>                      | Pressing of knuckle oil seal                   | MB990767-01<br>End yoke holder<br>             | Holding of end yoke  |
| MB991150<br>Dust cover installer<br>                       | Pressing of drive shaft dust cover             | MB990901-01<br>Pinion height gauge set<br>     | Adjustment of pinion height  |

| Tool (Number and name)  | Use  | Tool (Number and name)  | Use                                   |
|---|--|---|---------------------------------------|
| MB990802-01<br>Bearing installer<br>               | Pressing of drive pinion front bearing inner race<br>Pressing of side bearing inner race | MIT304180<br>Handle<br> | Pressing of the drive pinion oil seal |
| MB990031-01<br>Drive pinion oil seal installer<br> | Pressing of drive pinion oil seal  |   |                                       |

**TROUBLESHOOTING**

N02EA--

| Symptom   | Probable cause   | Remedy   | Reference page   |
|---|--|--|--|
| MANUAL FREE WHEELING HUB, FRONT AXLE HUB, KNUCKLE | Noise due to excessive play of wheel in turning direction  | Free wheeling hub serration play                     | Replace<br>2-33  |
|   | Noise due to excessive wheel end play  | Front axle hub bearing play, seizure, wear           | Check and adjust or replace if necessary<br>2-15<br>2-23 |
|   |  | Knuckle needle bearing play, seizure, wear           | Replace<br>2-46  |
|   |  | Free wheeling hub serration play                     | Replace<br>2-33  |
|   |  | Free wheeling hub looseness                          | Tighten or replace<br>2-29                               |
|   | AUTOMATIC FREE WHEELING HUB  |  |  |
| Does not lock                                     | Brake sliding portion worn   | Replace parts and adjust hub attaching surface shims | 2-21<br>2-25   |
|   | Brake (B) lug portion broken<br>Housing damaged<br>Drive gear damaged<br>Slide gear damaged<br>Retainer (A) damaged<br>Cam damaged<br>Shift spring deteriorated<br>Slide gear C ring out of position | Replace parts  | 2-25   |
|   | Automatic free wheeling hub attaching bolt loose   | Retighten attaching bolts                            | 2-18   |
| Locks but does not become free                    | Return spring deteriorated<br>Slide gear C ring out of position  | Replace parts  | 2-25   |
|   | Foreign substances on tooth surfaces of drive gear and slide gear<br>Foreign substances on tooth surfaces of slide gear and housing gear   | Clean tooth surfaces or replace parts                |  |
|   | Excessive front power train resistance   | Adjust differential preload                          | 2-21   |
| Ratcheting readily occurs                         | Water in brake portion   | Clean and then apply grease                          | 2-25   |
|   | Retainer (B) worn<br>Slide gear damaged<br>Housing gear damaged<br>Shift spring deteriorated<br>Slide gear C ring out of position  | Replace parts  |  |
|   | Automatic free wheeling hub attaching bolts loose  | Retighten the attaching bolts                        | 2-18   |

| Symptom   | Probable cause  | Remedy   | Reference page |
|---|---|--|----------------|
| DRIVE SHAFT, INNER SHAFT<br><br>Noise during wheel rotation | Housing tube bent<br>Inner shaft bent                             | Replace  | 2-62           |
|   | Inner shaft bearing worn, pounding                                | Replace  | 2-64           |
|   | Drive shaft assembly worn damaged, bent                           | Check or replace   | 2-52           |
| Noise due to excessive play of wheel in turning direction   | Inner shaft and side gear serration play                          | Replace  | 2-62<br>2-74   |
|   | Drive shaft and side gear serration play                          | Replace  | 2-52<br>2-74   |
|   | Drive shaft and drive flange serration play                       | Replace  | 2-52<br>2-62   |
| Noise due to excessive wheel end play                       | Drive shaft and drive flange end play                             | Adjust or replace  | 2-16           |
|   | Drive flange looseness  | Tighten or replace   | 2-62           |
| DIFFERENTIAL<br><br>Constant noise                          | Improper adjustment of drive gear and drive pinion (poor meshing) | Correct or replace   | 2-68           |
|   | Loose, worn or damaged side bearing                               | Correct or replace   | 2-73, 76       |
|   | Loose, worn or damaged drive pinion bearing                       | Correct or replace   | 2-73,<br>2-76  |
|   | Worn drive gear, drive pinion                                     | Correct or replace   | 2-73, 76       |
|   | Worn side gear thrust washer or pinion shaft                      | Replace  | 2-73, 76       |
|   | Deformed drive gear or differential case                          | Replace  | 2-73, 76       |
|   | Damaged gear  | Replace  | 2-73, 76       |
|   | Foreign material  | Eliminate the foreign material and check; replace the parts if necessary | 2-73,<br>2-76  |
|   | No oil  | Fill or change   | 2-16           |
| Gear noise while driving                                    | Poor gear engagement  | Correct or replace   | 2-69           |
|   | Improper gear adjustment  | Correct or replace   | 2-69           |
|   | Improper drive pinion preload adjustment                          | Correct or replace   | 2-77           |
|   | Damaged gear  | Replace  | 2-73, 76       |
|   | Foreign material  | Eliminate the foreign material and check; replace the parts if necessary | 2-73,<br>2-76  |
|   | Insufficient oil  | Fill or change   | 2-16           |

| Symptom                                 | Probable cause   | Remedy  | Reference page |
|---|--|---|----------------|
| Gear noise while coasting               | Improper drive pinion rotation torque adjustment         | Correct or replace                              | 2-77           |
|   | Damaged differential gear                                | Replace   | 2-73, 76       |
| Bearing noise while driving or coasting | Cracked or damaged drive pinion rear bearing             | Replace   | 2-73, 2-76     |
| Noise while turning                     | Loose side bearing                                       | Replace   | 2-73, 76       |
|   | Damaged side gear, pinion gear or pinion shaft           | Replace   | 2-73, 2-76     |
| Heat                                    | Improper differential gear backlash<br>Excessive preload | Adjust  | 2-69           |
|   | Insufficient oil   | Fill or change                                  | 2-16           |
| Oil leakage                             | Clogged vent plug  | Clean or replace the parts                      | –              |
|   | Cover tightened not<br>Seal malfunction                  | Retighten, apply sealant, or replace the gasket | 2-73, 2-76     |
|   | Worn or damaged oil seal                                 | Replace   | 2-73, 76       |
|   | Excessive oil  | Adjust the oil level                            | 2-16           |

## SERVICE ADJUSTMENT PROCEDURES

N02FBAC


### INSPECTION AND ADJUSTMENT OF WHEEL ALIGNMENT

1. Measure the wheel alignment with the vehicle parked on level ground and with the front wheels placed in the straight ahead positions.
2. Front suspension, steering system, wheels and tires should be serviced to normal condition prior to measurement of wheel alignment.


### TOE-IN

1. Measure the toe-in.

**Standard value : 2–9 mm (.08–.35 in.)**



2. If the toe-in does not agree with the standard value, use the left and right tie rod turnbuckles to adjust it.
3. Make the adjustment by turning the left and right turnbuckles the same amount in opposite directions. The toe-in value will decrease if the left turnbuckle is turned toward the front of vehicle and the right one is turned toward the rear, and vice a half-turn of the turnbuckles will result in an approximately 15 mm (.59 in.) adjustment in the toe-in.



### CAMBER


1. Remove the free-wheeling hub.
2. Measure the camber with a camber/caster/kingpin gauge.


**Standard value : 1°30'**

3. Make adjustment of the camber by increasing or decreasing the thickness of the adjusting shims between the upper arm shaft and the crossmember. A total of 4 mm (.16 in.) shim thickness is normally required for standard camber. A 1.0 mm (.039 in.) adjustment in thickness of shims will provide about 13 minutes adjustment of camber.

Camber adjustment shim (yellow plating)

| Part number | Thickness | mm (in.) |
|-------------|-----------|----------|
| MB176288    | 1.0       | (.039)   |
| MB176289    | 2.0       | (.079)   |






**CASTER**

1. Remove the free-wheeling hub.
2. Measure caster with a camber/caster/kingpin gauge and a turning radius gauge.

**Standard value : 2°57' ± 30'**



3. If caster does not meet specifications, remove the upper arm from the crossmember and then adjust by turning the upper arm shaft.  
A half turn of upper arm shaft will cause 1.25 mm (.049 in.) fore or aft movement of the upper arm shaft, resulting in about 17 minutes adjustment of caster.  
The adjustment must be made so that the difference between the caster's left side and right side is within 30 minutes.

**CHECKING FRONT AXLE TOTAL BACKLASH**

N02FDAA

1. If the vehicle vibrates and produces a booming sound due to the unbalance of the drivetrain, measure the front axle total backlash as follows to see if the differential carrier assembly requires removal.

(1) Set the hubs for 4WD.

**NOTE**

On vehicles with manual free-wheeling hubs, place the control handles in the LOCK position.


On vehicles with automatic free-wheeling hubs, place the transfer shift lever in 4H position and drive the vehicle 1 to 2 m (3.3 to 6.5 ft.) to engage the hubs with the drive shafts.


(2) Secure the wheels and set the transfer control lever to "2H".

**NOTE**

If the vehicle is raised on a jack, the wheels will turn and it will not be possible to measure the backlash.

(3) Turn the companion flange clockwise until all play is removed. Make mating marks on the dust cover of the companion flange and on the differential carrier.






11Y504

- (4) Turn the companion flange counterclockwise until all play is removed and measure the amount of distance through which the mating marks moved.
- (5) If the backlash exceeds the limit, remove the differential carrier assembly and adjust the backlash and drive shaft or inner shaft spline play.

**Limit : 14 mm (.55 in.)**

2. If the backlash exceeds the limit, remove the differential carrier assembly and final drive gear, and check for differential gear meshing condition and drive shaft or inner shaft spline looseness.



09F012

### CHECKING GEAR OIL LEVEL

N02FEAB

Remove the filler plug and check the oil level. The oil level should be somewhere within 8 mm (.31 in.) from the bottom of the filler plug hole.

**Specified gear oil : Hypoid gear oil API classification GL-4 or higher SAE viscosity No. 80W, 90 [1.10 lit. (1.16 U.S.qts., 0.97 Imp.qts.)]**

### CHECKING DRIVE SHAFT END PLAY

N02FFAA

#### VEHICLES WITH AUTOMATIC FREE-WHEELING HUBS

1. Place the free-wheeling hubs in the free condition.


#### NOTE

The free condition can be obtained by shifting the transfer shift lever to the 2H position and then moving in reverse for 1 to 2 m (3.3 to 6.5 ft.).

2. Jack the vehicle up and remove the front wheels.
3. Remove the free-wheeling hub covers.
4. Rotate the drive shaft forward, and backward and then set the drive shaft to the position (the position where end play is maximum) mid-way between where the rotation feels "heavy" for each (where there is a stopping feeling).
5. Set the dial gauge as shown in the figure; then move the drive shaft in the axial direction and measure the play.

**Standard value : 0.2–0.5 mm (.008–.020 in.)**

6. If the play is out of standard value, adjust by adding or removing shims.




11W029

#### VEHICLES WITH MANUAL FREE-WHEELING HUBS


1. Jack the vehicle up and remove the front wheels.
2. Move the control handles for the free-wheeling hub to the FREE position.
3. Remove the free-wheeling hub covers.
4. Set the dial gauge as shown in the figure; then move the drive shaft in the axial direction and measure the play.

**Standard value : 0.2–0.5 mm (.008–.020 in.)**

5. If the play is out of standard value, adjust by adding or removing shims.



11W070




## REPLACEMENT OF DIFFERENTIAL CARRIER OIL SEAL

N02FGAB

1. Remove the under cover. (Refer to 2-40.)
2. Remove the front hub and knuckle assembly.
3. Remove the left drive shaft. (Refer to 2-52.)

### Caution


**When pulling the left drive shaft from the differential carrier assembly, be careful that the drive shaft spline does not damage the oil seal.**




4. Remove the right drive shaft from the inner shaft assembly.
5. Remove the inner shaft assembly by using the special tools.

### Caution

**When pulling the inner shaft assembly from the differential carrier, be careful that the spline of the inner shaft does not damage the oil seal.**



6. Remove the differential mounting bracket (R.H.) and housing tube. (Refer to 2-66, 68.)
7. Use the special tool to remove the oil seal.



8. Press-fit the oil seal positively with the special tool and apply a thin coat of specified grease to the lip of the oil seal.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

9. Install the drive shaft using care not to damage the oil seal lip.

### NOTE

On R.H. side, after installation of the oil seal, install the housing tube and differential mounting bracket (R.H.). Install the inner shaft with care not to damage the oil seal lip, and install the drive shaft.


### Caution

**Be careful not to damage the lip of the oil seal. Replace the circlip which is attached to the B.J. side spline with a new one.**

10. Install the front hub and knuckle assembly.
11. Install the under cover.

## AXLE HUB AND FREE-WHEELING HUB

REMOVAL AND INSTALLATION (Vehicles with Automatic Free-Wheeling Hubs) N02GA--



### Removal steps

- ◄► 1. Cover
- ◆◆ Adjustment of drive shaft end play
- ◄► 2. Snap ring
- 3. Shim
- ◄► 4. Front brake assembly
- ◆◆ Adjustment of automatic free-wheeling hub turning resistance
- ◄► 5. Bolts
- ◆◆ 6. Automatic free-wheeling hub assembly
- ◆◆ Height adjustment of brake contact surface
- 7. Shim
- 8. Lock washer
- ◆◆ Adjustment of wheel bearing preload
- ◄► 9. Lock nut
- ◄► 10. Front hub assembly

### NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ◄► : Refer to "Service Points of Removal".
- (3) ◆◆ : Refer to "Service points of Installation".

N02GBAB

**SERVICE POINTS OF REMOVAL****1. REMOVAL OF COVER**

- (1) Place the free-wheeling hub in the free condition.


**NOTE**

The free condition can be obtained by shifting the transfer shift lever to the 2H position and then moving in reverse for 1 to 2 meters (3.3 to 6.5 ft.).

- (2) Remove the automatic free-wheeling hub cover.

**NOTE**


When the cover cannot be loosened by hand, use an oil filter wrench with a protective cloth in between not to damage the cover.



11W053

**2. REMOVAL OF SNAP RING**

Using a snap ring pliers, remove the snap ring from the drive shaft.




11S700

**4. REMOVAL OF FRONT BRAKE ASSEMBLY**

- (1) Remove the front brake assembly with the brake hose connected.
- (2) Use wire to suspend the front brake assembly from the upper arm so that the front brake assembly won't fall.

**Caution**


**Do not twist the brake hose.**



14S117


**5. REMOVAL OF BOLTS**

Remove the automatic free-wheeling hub by using the hexagonal wrench.



Hexagonal wrench

11W025


**9. REMOVAL OF LOCK NUT/10. FRONT HUB ASSEMBLY**

- (1) After the lock washer has been removed, remove the lock nut with the special tool.
- (2) Remove the front hub assembly from the knuckle together with the inner and outer bearings.

**INSPECTION**

N02GCAA

- Check the wheel bearing for seizure, discoloration and rough raceway surface.
- Check the front hub for cracks.
- Check the oil seals for cracks and damage.

**SERVICE POINTS OF INSTALLATION**

N02GDAB

● **ADJUSTMENT OF WHEEL BEARING PRELOAD**

- (1) Using the special tool, tighten the lock nut by the following procedures.


Tighten to 130-200 Nm (94-145 ft.lbs.)



Loosen to 0 Nm (0 ft.lbs.)




Retighten to 25 Nm (18 ft.lbs.) and then loosen 30°-40°



- (2) Loosen the lock nut approximately 30 to 40 degrees to adjust the front hub's turning resistance and play in the axial direction so that they agree with the standard values.

**Standard value : 30-130 Ncm**  
**(2.6-11.3 in.lbs.)**  
**[Spring scale reading]**  
**5-18 N (1.1-4.0 lbs.)**


**Standard value : 0.05 mm (.0020 in.) or less**



**NOTE**

If adjustment is not possible, the bearing may be incorrectly installed; check and, if necessary, repair. The lubrication condition should also be checked.

- (3) Mount the lock washer. If the lock washer holes do not align with the lock nut holes, loosen the lock nut (no more than 30 to 40 degrees) to align them.




- **HEIGHT ADJUSTMENT OF BRAKE CONTACT SURFACE**

Measure the height of brake contact surface.

- ① Using a depth gauge, measure the dimension A shown in illustration at two points.

**Standard value : 11.8–12.2 mm (.465–.480 in.)**

- ② If the average of the measured values is out of standard value, adjust by inserting shims.




- 6. **INSTALLATION OF AUTOMATIC FREE-WHEELING HUB ASSEMBLY**

- (1) Apply a coating of specified sealant, equally all around and without any missed spots, to the free-wheeling hub body assembly and front hub contact surfaces.

**Specified sealant : 3M ART Part No. 8661 or No. 8663, or equivalent**


**Caution**

**Make sure that there is no excess specified sealant on the hub outside surface.**



- (2) Align the key of the brake (B) and the keyway of knuckle spindle and loosely install the automatic free-wheeling hub assembly.

- (3) Check that the hub proper and automatic free-wheeling hub assembly are brought into intimate contact when the assembly is forced lightly against the hub proper. If not; turn the hub until intimate contact is achieved.




- **ADJUSTMENT OF AUTOMATIC FREE-WHEELING HUB TURNING RESISTANCE**

Check the automatic free-wheeling hub turning resistance by the following procedure.

- ① Use a spring scale to measure the front hub turning resistance again. Subtract the value measured in step (1) from that measured here to find the turning resistance of the free-wheeling hub.

Limit : 100 Ncm (8.7 in. lbs.)  
[Spring scale reading]  
14 N (3.1 lbs.)

- ② If the free-wheeling hub turning resistance exceeds the limit, disassemble and reassemble the free-wheeling hub again.



● **ADJUSTMENT OF DRIVE SHAFT END PLAY**

After the installation of shim and snap ring, check the drive shaft end play by the following procedure.


- ① Rotate the drive shaft forward, and backward and then set the drive shaft to the position (the position where end play is maximum) mid-way between where the rotation feels "heavy" for each (where there is a stopping feeling).  
Set the dial gauge as shown in the figure; then move the drive shaft in the axial direction and measure the play.

**Standard value : 0.2-0.5 mm (.008-.020 in.)**

- ② If the play is out of standard value, adjust by adding or removing shims.

DISASSEMBLY AND REASSEMBLY (Front Axle Hub)

N02HA--




Disassembly steps

- 1. Outer bearing
- ➡➡ 2. Oil seal
- 3. Inner bearing
- ↔ 4. Brake disc
- 5. Front hub

NOTE

- (1) Reverse the disassembly procedures to reassemble.
- (2) ↔ : Refer to "Service Points of Disassembly".
- (3) ➡➡ : Refer to "Service Points of Reassembly".
- (4) N : Non-reusable parts

11W041




SERVICE POINTS OF DISASSEMBLY

N02HBAA

4. REMOVAL OF BRAKE DISC

Make the mating marks on the brake disc and front hub, and then separate the front hub and brake disc, if necessary.




REPLACEMENT OF BEARING

N02HDAB

- (1) Remove the oil seal.
- (2) Wipe off grease from the front hub interior.
- (3) Using the drift against, drive out the inner and outer bearing outer races by tapping them uniformly.
- (4) Apply the specified grease to the outside surface of the new inner and outer bearing outer races.


**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**



- (5) Press-fit the inner and outer bearing outer races by using the special tools.

NOTE

The bearing inner race and bearing outer race should be replaced as an assembly.

**SERVICE POINTS OF REASSEMBLY**

N02HEAB

**2. INSTALLATION OF OIL SEAL**

- (1) Apply the specified grease to the oil seal lip and inside surface of the front hub.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

- (2) Apply the specified grease to the inner bearing inner race and install the inner race into the front hub.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

- (3) Press-fit the new oil seal into the front hub by using the special tools, until it is flush with the front hub end face.





**SERVICE POINTS OF DISASSEMBLY****4. REMOVAL OF HOUSING C RING**


Remove the housing C ring.

**NOTE**

The ring is easily removable by pushing the brake (B) in and using a small-end screwdriver, etc.

**8. REMOVAL OF HOUSING SNAP RING**

Remove the housing snap ring.

**9. REMOVAL OF RETAINER (B) C RING**


Using a special tool, lightly push the drive gear in and remove the retainer (B) C ring.

**NOTE**

Since the return spring relaxes approx. 40 mm (1.57 in.), the stroke of the press should be set to more than 40 mm (1.57 in.)

**Caution**


1. Place a protective cover not to damage the cover attaching surface of the housing before setting on the press table.
2. Make sure that the pressing force does not exceed 200 N (44.1 lbs.).

**10. REMOVAL OF DRIVE GEAR ASSEMBLY/11. SLIDE GEAR ASSEMBLY/12. RETURN SPRING**

Slowly reduce the pressure of the press until the return spring fully relaxes.

**Caution**

When the pressure of the press is removed, make sure that the retainer (A) is not caught by the retainer (B).




**15. REMOVAL OF DRIVE GEAR SNAP RING**

Remove the drive gear snap ring.

**Caution**

**When the drive gear snap ring is removed, be sure to replace it with a new one.**



**18. REMOVAL OF SLIDE GEAR C-RING**

Push the cam in and remove the slide gear C ring with the spring compressed.

**INSPECTION**

N02JCAA

- Check the drive gear and slide gear splines for damage.
- Check the cam portion of retainer (A) for wear and damage.
- Check the cam for wear and damage.
- Check the slide gear and housing tooth surfaces for damage.
- Check the retainer B and housing contact surfaces for wear and damage.

**BRAKE ASSEMBLY THICKNESS**

Check the brake assembly thickness by following the steps below.


- (1) Assemble brake (A) and brake (B) and then use slide calipers to measure the thickness of the assembly at the two lugs on brake (A).


**Standard value : 10.5 mm (.413 in.)**  
**Limit : 9.6 mm (.378 in.)**

**NOTE**

Measure each side separately.

- (2) If the measured value is below the limit, replace brake (A) and brake (B) as a set.



**DETERIORATION OF RETURN SPRING**

Check the return spring for deterioration by following the steps below.


- (1) Measure the dimension A shown in illustration at the opposite side of spring end.

**Limit : 35 mm (1.38 in.)**

**Caution**

**To measure the dimension A shown in illustration, measure the dimension from the outermost extremity of one wire diameter to that of the other wire diameter.**

- (2) If the measured value is below the limit, replace the spring.

**DETERIORATION OF SHIFT SPRING**

Check the shift spring for deterioration by following the steps below.

- (1) Measure the dimension B shown in illustration at the opposite side of spring end.

**Limit : 30 mm (1.18 in.)**

**Caution**

**To measure the dimension B shown in illustration, measure the dimension from the outermost extremity of one wire diameter to that of the other wire diameter.**

- (2) If the measured value is below the limit, replace the spring.

**SERVICE POINTS OF REASSEMBLY**

N02JDAB

Apply the specified grease to the attaching surfaces of all components.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

**13. APPLICATION OF GREASE TO RETAINER (B)**

Pack the grooves of retainer (B) with the specified grease.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

**12. INSTALLATION OF RETURN SPRING**

Install the return spring with the smaller coil diameter side toward the cam.


**5. APPLICATION OF GREASE TO BRAKE (B)**

Pack the grooves of brake (B) with the specified grease.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

REMOVAL AND INSTALLATION (Vehicles with Manual Free-Wheeling Hubs)

N02GA-




**Removal steps**

- ↔ 1. Free-wheeling hub cover
- ↔ 2. Gasket
- ↔↔ Adjustment of drive shaft end play
- ↔ 3. Snap ring
- ↔ 4. Shim
- ↔ 5. Front brake assembly
- ↔↔ 6. Manual free-wheeling hub assembly
- ↔ 7. Lock washer
- ↔↔ Adjustment of wheel bearing preload
- ↔ 8. Lock nut
- ↔ 9. Front hub assembly

**NOTE**


- (1) Reverse the removal procedures to reinstall.
- (2) ↔ : Refer to "Service Points of Removal".
- (3) ↔↔ : Refer to "Service Points of Installation".
- (4) N : Non-reusable parts

**SERVICE POINTS OF REMOVAL**


N02GBBA

**1. REMOVAL OF FREE-WHEELING HUB COVER**


- (1) Set the control handle to the FREE position.
- (2) Remove the free-wheeling hub cover.

**3. REMOVAL OF SNAP RING**

- Using a snap ring pliers, remove the snap ring from the drive shaft.

**5. REMOVAL OF FRONT BRAKE ASSEMBLY**

- (1) Remove the front brake assembly with the brake hose connected.
- (2) Use wire to suspend the front brake assembly from the upper arm so that the front brake assembly won't fall.


**Caution****Do not twist the brake hose.****8. REMOVAL OF LOCK NUT/9. FRONT HUB ASSEMBLY**

- (1) After the lock washer has been removed, remove the lock nut with the special tool.
- (2) Remove the front hub assembly from the knuckle together with the inner and outer bearings.

**INSPECTION**

N02GCAA

- Check the wheel bearing for seizure, discoloration and rough raceway surface.
- Check the front hub for cracks.
- Check the oil seal for cracks and damage.





**SERVICE POINTS OF INSTALLATION**

N02GDBB


● **ADJUSTMENT OF WHEEL BEARING PRELOAD**

- (1) Using the special tool, tighten the lock nut by the following procedure.



- (2) Loosen the lock nut approximately 30 to 40 degrees to adjust the front hub's turning resistance and play in the axial direction so that they agree with the standard values.


**Standard value : 30-130 Ncm (2.6-11.3 in.lbs.)**  
**[Spring scale reading]**  
**5-18 N (1.1-4.0 lbs.)**  
**Standard value : 0.05 mm (.0020 in.) or less**



**NOTE**

If adjustment is not possible, the bearing may be incorrectly installed; check and, if necessary, repair. The lubrication condition should also be checked.

- (3) Mount the lock washer. If the lock washer holes do not align with the lock nut holes, loosen the lock nut (no more than 30 to 40 degrees) to align them.




**6. INSTALLATION OF MANUAL FREE-WHEELING HUB ASSEMBLY**

Apply a coating of specified sealant, equally all around and without any missed spots, to the free wheeling hub body assembly and front hub contact surfaces.

**Specified sealant : 3M ART Part No. 8661, No. 8663, or equivalent**

**Caution**

**Make sure that there is no excess specified sealant on the hub outside surface.**



- **ADJUSTMENT OF DRIVE SHAFT END PLAY**

After assembly in the order of the shim and then the snap ring, check the drive shaft end play.

Set the dial gauge as shown in the figure; then move the drive shaft in the axial direction and measure the play.

**Standard value : 0.2–0.5 mm (.008–.020 in.)**

If the play is out of standard value, adjust by adding or removing shims.


**DISASSEMBLY AND REASSEMBLY (Front Axle Hub)**

N02HA--

Refer to P.2-23.

**DISASSEMBLY AND REASSEMBLY (Manual free-Wheeling Hub)**

N02JA--




**Disassembly steps**

- ◆◆ 1. Free wheeling hub cover
- ◆◆ 2. Gasket
- ◆◆ 3. Free wheeling hub clutch
- ◆◆ 4. Compression spring
- ◆◆ 5. Follower
- ◆◆ 6. Tension spring
- ◆◆ 7. Free wheeling hub body
- ◆◆ 8. Wheel snap ring
- ◆◆ 9. Inner hub
- ◆◆ 10. Shaft snap ring
- ◆◆ 11. Free wheeling hub ring
- ◆◆ 12. Spacer

**NOTE**

- (1) Reverse the disassembly procedures to reassemble.
- (2) ◆◆ : Refer to "Service Points of Disassembly".
- (3) ◆◆ : Refer to "Service Points of Reassembly".
- (4) N : Non-reusable parts

11W574



**SERVICE POINTS OF DISASSEMBLY**

N02JBBA



**8. REMOVAL OF WHEEL SNAP RING/10. SHAFT SNAP RING**

- (1) Using a screwdriver, remove the snap ring and remove the inner hub from the free wheeling hub body.
- (2) Remove the snap ring from the inner hub with a snap ring pliers.

**INSPECTION**

N02JCBA

- Check the free wheeling hub ring, inner hub, free wheeling hub body, and clutch for wear or seizure.
- Check the gasket for damage.
- Check the compression spring and tension spring for deterioration.

**SERVICE POINTS OF REASSEMBLY**

N02JDBB

**11. APPLICATION OF GREASE TO FREE WHEELING HUB RING/9. INNER HUB/7. FREE WHEELING HUB BODY/3. FREE WHEELING HUB CLUTCH/1. FREE WHEELING HUB COVER**

- (1) Apply the specified grease to the entire periphery of the free wheeling hub ring, inner hub and free wheeling hub clutch, free wheeling hub cover and the inside of the free wheeling hub body.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**


- (2) Check to be sure that the hub body assembly and hub cover assembly are coated (at the positions shown in the figure) with a sufficient coating of the specified grease.
- (3) Add more grease if necessary.

**NOTE**

A liberal amount of grease should be applied, especially when grease is wiped away or a new free-wheeling hub is installed.

# SHOCK ABSORBER AND UPPER ARM REMOVAL AND INSTALLATION

N02MA--



12W557

### Post-installation Operation

- Inspection and Adjustment of Wheel Alignment (Refer to P.2-14.)

### Shock absorber removal steps


- ◆◆ 1. Shock absorber

### Upper arm removal steps

- ◆◆ Adjustment of clearance between bump stopper and bump stopper bracket
- ◆◆ 2. Anchor arm assembly adjusting nut
- ◆◆ 3. Hose clip
- ◆◆ 4. Connection of brake hose
- ◆◆ 5. Cotter pin
- ◆◆ 6. Connection of upper ball joint and knuckle
- ◆◆ 7. Brake hose support
- ◆◆ 8. Rebound stopper
- ◆◆ 9. Shim
- ◆◆ ◆◆ 10. Upper arm

### NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ◆◆ : Refer to "Service Points of Removal".
- (3) ◆◆ : Refer to "Service Points of Installation".
- (4) **N** : Non-reusable parts

**SERVICE POINTS OF REMOVAL**


N02MBAA

**2. LOOSENING OF ANCHOR ARM ASSEMBLY ADJUSTING NUT**

Loosen the anchor bolt of the torsion bar all the way.

**NOTE**

When the anchor arm assembly adjusting nut is loosened, use a jack to support the lower arm of the side to be loosened, thus the work easier.

**6. DISCONNECTION OF UPPER BALL JOINT FROM KNUCKLE**

- (1) Loosen the nut tightening the upper ball joint to the knuckle.


**NOTE**

The nut should be partially loosened and should not be removed.

- (2) Using a special tool, disconnect the upper ball joint from the knuckle.

**Caution**

**Tie the special tool to the upper arm, for example, with a string to prevent bouncing.**

**10. REMOVAL OF UPPER ARM**

Remove the upper arm from the crossmember.

**NOTE**


The camber adjustment shims should be stored for reference at assembly.

Do not turn the upper arm shaft, as it changes caster.


**INSPECTION**

N02MCAA

- Check the upper arm for cracks or deformation.
- Check the upper arm shaft for cracks or bends.

**SHOCK ABSORBER**

Expand and contract the shock absorber to check it for damage, oil leakage or abnormal noise.




**UPPER ARM SHAFT STARTING TORQUE**

Check the upper arm shaft starting torque by following the steps below.

1. With the upper arm shaft held in a vice, measure the upper arm shaft starting torque with a spring balance.

**Limit : 15 Nm (11ft.lbs.)**  
**[Spring scale reading]**  
**6.8 N (1.5 lbs.)**

2. If the upper arm shaft starting torque exceeds the limit, replace the upper arm assembly




**UPPER BALL JOINT STARTING TORQUE**

Check the upper ball joint starting torque by following the steps below.

1. Measure the upper ball joint starting torque with a torque wrench.

**Standard value : 80–350 Ncm (7–30 in.lbs.)**

2. If the upper ball joint starting torque is out of specification, replace the upper ball joint.




**UPPER ARM SHAFT TIGHTENING AMOUNT**

Give appropriate amount of turn to the shaft so as to obtain the specified dimension.

**Caution**


**The dimensions shown in the illustration are important dimensions that determine the caster.**







**REPLACEMENT OF UPPER BALL JOINT**

NO2MDAB

1. Remove the dust cover together with the ring.
2. Remove the snap ring from the upper ball joint by using a snap ring pliers.



3. Press the upper ball joint out of the upper arm by using the special tools.



- Press-fit the new upper ball joint with special tools aligning the mating mark with the upper arm center.

- Using a snap ring pliers, fit the snap ring securely in the groove of the joint case.

#### Caution

Limit the opening of the snap ring to a minimum.

- Apply the specified grease to both the interior of dust cover and the upper ball joint.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

- Apply the specified sealant to the grooves in the upper ball joint.

**Specified sealant : 3M ART Part No. 8663, No. 8661 or equivalent**

- Secure the dust cover to the upper ball joint with a ring.

### SERVICE POINTS OF INSTALLATION


N02MEAA

#### 10. INSTALLATION OF UPPER ARM

When the upper arm assembly is installed to the crossmember, insert the upper arm shaft attaching bolts from outside the crossmember and put adjusting shims between the crossmember and upper arm shaft.

- ADJUSTMENT OF CLEARANCE BETWEEN BUMP STOPPER TO BUMP STOPPER BRACKET**


Refer to P.2-49.



**1. INSTALLATION OF SHOCK ABSORBER**

- (1) Tighten the shock absorber installation nut so that the dimension shown in the figure is the standard value.

**Standard value : 7-8 mm (.27-.31 in.)**




- (2) Install the shock absorber so that the white paint mark at the lower side of the shock absorber faces the outer side of the vehicle.

LOWER ARM

REMOVAL AND INSTALLATION

N02NA--



**Post-installation Operation**  
 • Inspection and Adjustment of Wheel Alignment (Refer to P.2-14.)

**Removal steps**

1. Under skid plate
2. Under cover
- ◆◆ Adjustment of clearance between bump stopper and bump stopper bracket
- ◆◆◆◆ 3. Torsion bar
- ◆◆ 4. Cotter pin
- ◆◆ 5. Connection of lower ball joint and knuckle
- ◆◆ 6. Self-locking nut
- ◆◆ 7. Stabilizer bar
- ◆◆ 8. Shock absorber mounting bolts

9. Lower arm shaft
10. Anchor arm B
11. Lower arm
12. Bump stopper
13. Lower ball joint mounting nuts


**NOTE**  
 (1) Reverse the removal procedures to reinstall.  
 (2) ◆◆ : Refer to "Service Points of Removal".  
 (3) ◆◆◆◆ : Refer to "Service Points of Installation".  
 (4) [N] : Non-reusable parts  
 (5) \* : Must be tightened while vehicle is unladen.

**SERVICE POINTS OF REMOVAL**

N02NBAA

**3. REMOVAL OF TORSION BAR**

Refer to P.2-48.


**5. DISCONNECTION OF LOWER BALL JOINT FROM KNUCKLE**

- (1) Loosen the nut tightening the lower ball joint to the knuckle.

**NOTE**

The nut should be partially loosened and should not be removed.

- (2) Using a special tool, disconnect the lower ball joint from the knuckle.


**8. REMOVAL OF SHOCK ABSORBER MOUNTING BOLTS**

Remove the shock absorber lower part and compress the shock absorber.

**INSPECTION**

N02NCAA

- Check the lower arm for cracks or deformation.
- Check the anchor arm assembly for wear or damage.
- Check the lower ball joint dust cover for cracks or deterioration.


**LOWER BALL JOINT END PLAY**

Check the lower ball joint end play by following the steps below.

1. Measure the lower ball joint end play with a dial indicator.

**Limit : 0.5 mm (.020 in.)**

2. If the lower ball joint end play exceeds the limit, replace the lower ball joint.




## REPLACEMENT OF LOWER ARM BUSHING

NO2NDAA


- Using a special tool, remove the bushing A from the bracket.

### NOTE


When removing the left hand bushing A, detach the differential carrier. (Refer to P.2-69.)



- Using a special tool, press-fit the bushing A into the bracket.



- Remove the bushing B from the lower arm by using special tools.



- Coat the bushing B and the lower arm with soap solution and press-fit the bushing B into the lower arm by using special tools and taking care not to twist or tilt the bushing B.

### NOTE

Press-fit the bushing again from the opposite side to equalize bushing projections at both ends.

## REPLACEMENT OF LOWER BALL JOINT DUST COVER


NO2NEAB

- Apply the specified grease to the interior of the dust cover and the lower ball joint.


**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

- Apply the specified sealant to the grooves in the lower ball joint.

**Specified sealant : 3M ART Part No. 8663, No. 8661 or equivalent**



- Secure the dust cover to the lower ball joint with a ring.

**SERVICE POINTS OF INSTALLATION**

N02NFAA

**7. INSTALLATION OF STABILIZER BAR**

Install the stabilizer bar to the lower arm in such a way that the amount of protrusion of the stabilizer bar installation bolt is the standard value.

**Standard value : 6–8 mm (.24–.31 in.)**

**NOTE**

The dimension show in figure is the value when a new bushing is used.

**3. INSTALLATION OF TORSION BAR**

Refer to P.2-48.


**● ADJUSTMENT OF CLEARANCE BETWEEN BUMP STOPPER AND BUMP STOPPER BRACKET**

Refer to P.2-49

## KNUCKLE

## REMOVAL AND INSTALLATION

N02PA--



11W611

## Removal steps

- ◆◆◆ 1. Front axle hub and free-wheeling hub
- 2. Dust cover
- 3. Cotter pin
- ◆◆ 4. Connection of tie rod assembly and knuckle
- 5. Cotter pin
- ◆◆ 6. Connection of lower ball joint and knuckle
- 7. Cotter pin
- ◆◆ 8. Connection of upper ball joint and knuckle
- 9. Knuckle

## NOTE


- (1) Reverse the removal procedures to reinstall.
- (2) ◆◆ : Refer to "Service Points of Removal".
- (3) ◆◆◆ : Refer to "Service Points of Installation".
- (4) N : Non-reusable parts

**SERVICE POINTS OF REMOVAL**

N02PBAA

**1. REMOVAL OF FRONT AXLE HUB AND FREE WHEELING HUB**

For models equipped with the automatic free-wheeling hub, refer to page 2-18; for models equipped with the manual free-wheeling hub, refer to page 2-29.




**4. DISCONNECTION OF TIE ROD ASSEMBLY FROM KNUCKLE**

Disconnect the tie rod from the knuckle by using the special tool.

**Caution**

1. Use cord to bind the special tool closely so it won't become separated.
2. The nut should be loosened only, not removed.



**6. DISCONNECTION OF LOWER BALL JOINT FROM KNUCKLE/8. UPPER BALL JOINT FROM KNUCKLE**

Using the special tool, remove the lower ball joint and upper ball joint.

**Caution**

1. Support the lower arm with a jack when removing the knuckle from the lower ball joint or the upper ball joint.
2. After the knuckle has been removed, lower the jack slowly.

**INSPECTION**

N02PCAA

- Check the needle bearing for wear or damage.
- Check the knuckle for cracks or bends.
- Check the knuckle spindle for wear or pounding.

**SERVICE POINT OF INSTALLATION**

N02PDAA

**1. INSTALLATION OF FRONT AXLE HUB AND FREE-WHEELING HUB**

For models equipped with the automatic free-wheeling hub, refer to page 2-18; for models equipped with the manual free-wheeling hub, refer to page 2-29.

## DISASSEMBLY AND REASSEMBLY


N02PE--

## Disassembly steps


- ◆◆ 1. Oil seal
- ◆◆ 2. Spacer
- ◆◆◆◆ 3. Needle bearing
- 4. Knuckle

## NOTE

- (1) Reverse the disassembly procedures to reassemble.
- (2) ◆◆ : Refer to "Service Points of Disassembly".
- (3) ◆◆◆◆ : Refer to "Service Points of Reassembly".
- (4) **N** : Non-reusable parts



11W605



11W563

## SERVICE POINTS OF DISASSEMBLY


N02PFAA

## 3. REMOVAL OF NEEDLE BEARING

- (1) Remove the oil seal and take out the spacer.
- (2) Drive out the needle bearing by tapping needles uniformly.

## Caution

Once removed, the needle bearing must not be reused.



11S149

## SERVICE POINTS OF REASSEMBLY

N02PGAB

## 3. INSTALLATION OF NEEDLE BEARING


- (1) Apply the specified grease to the roller surface of the new needle bearing.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

- (2) Press-fit the needle bearing by using the special tools, until it is flush with the knuckle end face.

## Caution

Use care to prevent driving the needle bearing too far in.




## 2. INSTALLATION OF SPACER

- (1) Apply the specified grease to the knuckle attaching surface of the spacer.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

- (2) Install the spacer to the knuckle with the chamfered side toward the center or vehicle.



## 1. INSTALLATION OF OIL SEAL


- (1) Press-fit the new oil seal by using the special tools, until it is flush with the knuckle end face.
- (2) Pack the specified grease in the oil seal inside and lip.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**

**TORSION BAR**

**REMOVAL AND INSTALLATION**

N02SA--



12W558

**Removal steps**

- 1. Heat protector (right side only)
- ◆◆ Adjustment of clearance between bump stopper and bump stopper bracket
- ◆◆ 2. Anchor arm assembly
- 3. Dust covers
- ◆◆ 4. Heat cover (left side only)
- ◆◆ 5. Torsion bar

**NOTE**

- (1) Reverse the removal procedures to reinstall.
- (2) ◆◆ : Refer to "Service Points of Removal".
- (3) ◆◆ : Refer to "Service Points of Installation".

**SERVICE POINTS OF REMOVAL**

N02SBAA

**2. REMOVAL OF ANCHOR ARM ASSEMBLY**

Support the lower arm from which the torsion bar is to be removed, with a jack.

**INSPECTION**

N02SCAA


- Check the torsion bar for bends or damage.
- Check the dust cover for cracks or damage.

**SERVICE POINTS OF INSTALLATION**


N02SDAB

Apply the specified grease to the torsion bar serrations, the anchor arm assembly serrations, the anchor arm B serrations, the dust cover inside and the anchor bolt thread.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**



12W535




**5. INSTALLATION OF TORSION BAR**

- (1) Identify the right and left torsion bars referring to the identification mark put on the torsion bars. Face the end having identification mark forward, and align the mark on anchor arm B with the mating mark on torsion bar when the torsion bar is inserted in the anchor arm B.


**NOTE**

When installing a new torsion bar, align the serration painted white with the mark on anchor arm B.



- (2) Select the relative position of the torsion bar serrations and the anchor arm serrations so that the length shown in the illustration may have specified dimension when the torsion bar and the anchor arm are assembled, with the upper arm rebound stopper in contact with the crossmember.

**Standard value : L.H. 135.2–143.2 mm (5.323–5.638 in.)**  
**R.H. 124.3–132.3 mm (4.894–5.210 in.)**



**● ADJUSTMENT OF CLEARANCE BETWEEN BUMP STOPPER AND BUMP STOPPER BRACKET**

- (1) Use the curb weight to obtain the amount of anchor bolt projection from the following table.

**NOTE**

The anchor bolt projection amount is a reference dimension used when the torsion bar spring is installed.

Finally, adjust so that the distance to the bump stopper bracket is the standard value.

This method can also be used to make the adjustment on previously sold vehicles.


**Example**

For a vehicle with a curb weight of 1,440 kg (3,175 lbs.), the table shows the following left and right anchor bolt projections.


Left ..... 60 mm (2.36 in.)  
 Right ..... 71 mm (2.80 in.)

**NOTE**

For curb weights of the various models, refer to "INTRODUCTION AND MASTER TROUBLESHOOTING - General Date and Specifications".



14W031




- (2) With the vehicle unladen, measure the dimension from the bump stopper to the bump stopper bracket to check for conformance with standard value.

**Standard value : 71 mm (2.80 in.)**

- (3) If it is out of specification, adjust with the adjusting nut on the anchor bolt.

**STABILIZER BAR  
REMOVAL AND INSTALLATION**

N02TA--



**Removal steps**

1. Under skid plate
2. Self-locking nut
3. Clamp A
4. Stabilizer bushing
5. Self-locking nut
6. Hanger
- ◆◆ 7. Stabilizer bar

**NOTE**

- (1) Reverse the removal procedures to reinstall.
- (2) ◆◆ : Refer to "Service Points of Installation".
- (3) **N** : Non-reusable parts.

**INSPECTION**

N02TCAA

- Check the stabilizer bar for deformation or damage.
- Check the hanger for bends or damage.
- Check the rubber parts for cracks, deterioration or wear.

**SERVICE POINTS OF INSTALLATION**

N02DAA

**7. INSTALLATION OF STABILIZER BAR**

When installing the hanger to the stabilizer bracket, tighten the nut so as to obtain the specified dimension.


**Standard value : 6-8 mm (.24-.31 in.)**

When installing both ends of the stabilizer bar to the lower arms, tighten the nut so as to obtain the specified dimension.

**Standard value : 6-8 mm (.24-.31 in.)**

**NOTE**


The dimension shown in the figure is the value when a new bushing is used.



DRIVE SHAFT

REMOVAL AND INSTALLATION

NO2QA--




Removal steps

- 1. Under cover
- ◄◄ 2. Cover  
(automatic free-wheeling hub)
- ◄◄ 3. Free-wheeling hub cover  
(manual free-wheeling hub)
- 4. Gasket (manual free-wheeling hub)
- ◆◆ Adjustment of driveshaft end play
- ◄◄ 5. Snap ring
- 6. Shim
- ◄◄ 7. Front brake assembly
- 8. Cotter pin
- ◄◄ 9. Connection of tie rod assembly and  
knuckle
- 10. Cotter pin
- ◄◄ 11. Connection of lower ball joint and  
knuckle
- 12. Cotter pin
- ◄◄ 13. Connection of upper ball joint and  
knuckle
- 14. Front hub and knuckle assembly
- ◄◄ ◆◆ 15. Left drive shaft
- 16. Circlip
- 17. Right drive shaft

11W581

NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ◄◄ : Refer to "Service Points of Removal".
- (3) ◆◆ : Refer to "Service Points of Installation".
- (4) N : Non-reusable parts

**SERVICE POINTS OF REMOVAL**

NO20BAC

**2. REMOVAL OF COVER (Automatic free wheeling hub)**

- (1) Place the free-wheeling hub in the free condition.


**NOTE**

The free condition can be obtained by shifting the transfer shift lever to the 2H position and then moving in reverse for 1 to 2 meters. (3.3 to 6.5 ft.)


- (2) Remove the automatic free wheeling hub cover.

**NOTE**


When the cover cannot be loosened by hand, use an oil filter wrench with a protective cloth in between not to damage the cover.

**3. REMOVAL OF FREE WHEELING HUB COVER (Manual free wheeling hub)**

- (1) Set the control handle to the FREE position.
- (2) Remove the free wheeling hub cover.

**5. REMOVAL OF SNAP RING**


Using a snap ring pliers, remove the snap ring from the drive shaft.

**7. REMOVAL OF FRONT BRAKE ASSEMBLY**

- (1) Remove the front brake assembly with the brake hose connected.
- (2) Use wire to suspend the front brake assembly from the upper arm so that the front brake assembly won't fall.

**Caution**

**Do not twist the brake hose.**




### 9. DISCONNECTION OF TIE ROD ASSEMBLY FROM KNUCKLE

Disconnect the tie rod from the knuckle by using the special tool.

#### Caution

1. Use cord to bind the special tool closely so it won't become separated.
2. The nut should be loosened only, not removed.




### 11. DISCONNECTION OF LOWER BALL JOINT FROM KNUCKLE/13. UPPER BALL JOINT FROM KNUCKLE

Using the special tool, remove the lower ball joint and upper ball joint.

#### Caution

1. Support the lower arm with a jack when removing the knuckle from the lower ball joint or the upper ball joint.
2. After the knuckle has been removed, lower the jack slowly.



### 15. REMOVAL OF LEFT DRIVE SHAFT

Pull the drive shaft out from the differential carrier.

#### Caution

When pulling the drive shaft out from the differential carrier, be careful that the spline part of the drive shaft does not damage the oil seal.

## INSPECTION

N020CAB

- Check the boot for damage or deterioration.
- Check the ball joint for operating condition and excessive looseness.
- Check the splines for wear or damage.

## SERVICE POINTS OF INSTALLATION


N020DAC


### 15. INSTALLATION OF LEFT DRIVE SHAFT

Drive the drive shaft into the front differential carrier with a plastic hammer.

#### Caution

Be careful not to damage the lip of the oil seal. Replace the circlip which is attached to the D.O.J. side spline part with a new one.






- **ADJUSTMENT OF DRIVE SHAFT END PLAY**

**Vehicles with automatic free-wheeling hubs**

- (1) Rotate the drive shaft forward, and backward and then set the drive shaft to the position (the position where end play is maximum) mid-way between where the rotation feels "heavy" for each (where there is a stopping feeling).
- (2) Set the dial gauge as shown in the figure; then move the drive shaft in the axial direction and measure the play.

**Standard value : 0.2–0.5 mm (.008–.020 in.)**

- (3) If the play is out of standard value, adjust by adding or removing shims.


**Vehicles with manual free-wheeling hubs**



- (1) Set the dial gauge as shown in the figure; then move the drive shaft in the axial direction and measure the play.

**Standard value : 0.2–0.5 mm (.008–.020 in.)**

- (2) If the play is out of standard value, adjust by adding or removing shims.


DISASSEMBLY AND REASSEMBLY

Left drive shaft




Drive shaft kit LH

11W606




D.O.J. kit

11W607



Boot repair kit (B.J.)

11W608



Boot repair kit (D.O.J.)

11W609

11B0025

Disassembly steps

- 1. Boot band A
- 2. Boot band B
- 3. Circlip
- 4. D.O.J. outer race
- 5. Balls
- 6. D.O.J. cage
- 7. Snap ring
- 8. D.O.J. inner race
- 9. D.O.J. boot
- 10. Dust cover
- 11. Boot protector band
- 12. Boot protector
- 13. Boot band A
- 14. Boot band B
- 15. B.J. boot
- 16. Drive shaft and B.J.
- 17. Circlip

Reassembly steps


- 16. Drive shaft and B.J.
- 15. B.J. boot
- 13. Boot band A
- 14. Boot band B
- 2. Boot band B
- 9. D.O.J. boot
- 1. Boot band A
- 6. D.O.J. cage
- 8. D.O.J. inner race
- 7. Snap ring
- 5. Balls
- 4. D.O.J. outer race
- 3. Circlip
- 17. Circlip
- 12. Boot protector
- 11. Boot protector band
- 10. Dust cover

NOTE


(1) ⇄ : Refer to "Service Points of Disassembly".  
 (2) ⇄ : Refer to "Service Points of Reassembly".

(3) [N] : Non-reusable parts  
 (4) B.J. : Birfield Joint  
 (5) D.O.J. : Double Offset Joint

Right drive shaft




11B0025




11W606

Drive shaft kit RH




11W607

D.O.J. kit



11W608

Boot repair kit (B.J.)



11W609

Boot repair kit (D.O.J.)

Disassembly steps

1. Boot band A
2. Boot band B
3. Circlip
4. D.O.J. outer race
- ◄◄ 5. Balls
- ◄◄ 6. D.O.J. cage
- ◄◄ 7. Snap ring
- ◄◄ 8. D.O.J. inner race
- ◄◄ 9. D.O.J. boot
- ◄◄ 10. Dust cover
- ◄◄ 11. Boot protector band
- ◄◄ 12. Boot protector
- ◄◄ 13. Boot band A
- ◄◄ 14. Boot band B
- ◄◄ 15. B.J. boot
- ◄◄ 16. Drive shaft and B.J.


Reassembly steps

16. Drive shaft and B.J.
- ◄◄ 15. B.J. boot
- ◄◄ 13. Boot band A
- ◄◄ 14. Boot band B
- ◄◄ 2. Boot band B
- ◄◄ 9. D.O.J. boot
- ◄◄ 1. Boot band A
- ◄◄ 6. D.O.J. cage
- ◄◄ 8. D.O.J. inner race
- ◄◄ 7. Snap ring
- ◄◄ 5. Balls
- ◄◄ 4. D.O.J. outer race
- ◄◄ 3. Circlip
- ◄◄ 12. Boot protector
- ◄◄ 11. Boot protector band
- ◄◄ 10. Dust cover


NOTE

- (1) ◄◄ : Refer to "Service Points of Disassembly".  
 (2) ◄◄ : Refer to "Service Points of Reassembly".


- (3) **N** : Non-reusable parts  
 (4) B.J. : Birfield Joint  
 (5) D.O.J. : Double Offset Joint

**SERVICE POINTS OF DISASSEMBLY****5. REMOVAL OF BALLS**


Remove the balls from the D.O.J. cage.

**6. REMOVAL OF D.O.J. CAGE**


Remove the D.O.J. cage from the D.O.J. inner race in the direction of the B.J.

**7. REMOVAL OF SNAP RING**


Remove the snap ring from the drive shaft with a snap ring pliers, and then withdraw the D.O.J. Inner race and D.O.J. cage from the drive shaft.

**9. REMOVAL OF D.O.J. BOOT**

- (1) Wrap vinyl tape around the spline part on the D.O.J. side of the drive shaft so that the D.O.J. boots are not damaged when they are removed.
- (2) Withdraw the D.O.J. boots from the drive shaft.


**10. REMOVAL OF DUST COVER**

Remove the dust cover from the drive shaft and B.J.



**12. REMOVAL OF BOOT PROTECTOR**

After extending the folded over part of the boot protector and removing the boot protector band, push the boot protector to the B.J. side and then remove it.



**15. REMOVAL OF B.J. BOOT**

- (1) Wrap vinyl tape around the spline part on the D.O.J. side of the drive shaft so that the B.J. boot are not damaged when they are removed.
- (2) Withdraw the B.J. boot from the drive shaft.

**Caution**  
Do not disassemble the B.J.

**INSPECTION**

N020GAB

- Check the drive shaft for bending or wear.
- Check the B.J. for entry of water, foreign matter and rust.
- Check the B.J. ball for damage.
- Check the D.O.J. cage, D.O.J. inner race and ball for rust, wear and damage.
- Check the circlip for damage or deformation.
- Check the D.O.J. outer race for wear or damage.

**SERVICE POINTS OF REASSEMBLY**

N020HAB


**15. INSTALLATION OF B.J. BOOT / 13. BOOT BAND A / 14. BOOT BAND B / 2. BOOT BAND B / 9. D.O.J. BOOT / 1. BOOT BAND A**


- (1) Apply the specified grease to the drive shaft, and wrap vinyl tape around the spline part on the D.O.J. side of the drive shaft.

**Specified grease : Repair kit grease**

- (2) Install the B.J. boot, boot bands (new ones), and D.O.J. boot on the drive shaft, in that order.


**Caution**  
The B.J. and D.O.J. boots are different in size and shape, so make sure they are correct.





- (3) Apply all the specified grease, half of it to the inner side of the B.J., and the other half to the inner side of the B.J. boot.


**Specified grease : Repair kit grease [110 gr (3.9 oz.)]**



- (4) Secure the B.J. boot to the driveshaft by boot bands A and B.

**Caution**


**Be sure that the installation direction of the boot bands is correct.**



**6. INSTALLATION OF D.O.J. CAGE / 8. D.O.J. INNER RACE**

- (1) Install the D.O.J. cage onto the drive shaft so that the smaller diameter side of the cage is installed first.  
 (2) Apply the specified grease to the D.O.J. inner race and the D.O.J. cage, and then fit them together.


**Specified grease : Repair kit grease**



**5. APPLICATION OF GREASE TO BALLS**

Apply the specified grease to the ball insertion parts of the D.O.J. inner race and D.O.J. cage, and insert the balls.

**Specified grease : Repair kit grease**





**4. INSTALLATION OF D.O.J. OUTER RACE**

- (1) Apply the specified grease to the D.O.J. outer race.

**Specified grease : Repair kit grease  
 [55 gr (1.9 oz.)]**

- (2) Fit the drive shaft into the D.O.J. outer race.  
 (3) Add the specified grease to the D.O.J. outer race.

**Specified grease : Repair kit grease  
 [55 gr (1.9 oz.)]**



- (4) Install the circlip onto the D.O.J. outer race.
- (5) Place the D.O.J. boot over the D.O.J. outer race, and then use boot band B to secure the boot.

**Caution**

**Be sure that the installation direction of the boot bands is correct.**

- (6) Replace the boot band A on D.O.J. boot.

**Caution**

**Do not secure the boot band A**


- (7) Secure the driveshaft, and then move the D.O.J. outer race until it is at the position where the D.O.J. boot assembly dimension is the standard value.

**Standard value : 77–83 mm (3.03–3.27 in.)**

- (8) Remove a part of the D.O.J. boot from the D.O.J. outer race and release the air within the boot.
- (9) Secure the boot band A on D.O.J. boot.

**Caution**

**Be sure that the installation direction of the boot bands is correct.**




**12. INSTALLATION OF BOOT PROTECTOR / 11. BOOT PROTECTOR BAND**

- (1) After installing the boot protector to the B.J., secure by the boot protector band.

**Caution**

**Be sure that the installation direction of the boot bands is correct.**

- (2) Securely fold over the end of the boot protector.



**10. INSTALLATION OF DUST COVER**


Using the steel pipe as specified below, force the dust cover to the drive shaft.

| Steel Pipe       | mm (in.)    |
|------------------|-------------|
| Overall length   | 170 (6.70)  |
| Outside diameter | 68.9 (2.71) |
| Wall thickness   | 2.3 (.09)   |

## INNER SHAFT

## REMOVAL AND INSTALLATION

N02RA--



## Removal steps

1. Under cover
- ◄◄ ◄◄ 2. Front hub and knuckle assembly
- ◄◄ ◄◄ 3. Shock absorber lower mounting bolts
- ◄◄ ◄◄ 4. Drive shaft assembly (R.H.)
- ◄◄ ◄◄ 5. Inner shaft
6. Circlip
7. Self locking nut
8. Differential mounting bracket (R.H.)
9. Housing tube

11W582

## NOTE


- (1) Reverse the removal procedures to reinstall.
- (2) ◄◄ ◄◄ : Refer to "Service Points of Removal".
- (3) ◄◄ ◄◄ : Refer to "Service Points of Installation".
- (4) **N** : Non-reusable parts

**SERVICE POINTS OF REMOVAL**

N02RBAB

**2. REMOVAL OF FRONT HUB AND KNUCKLE ASSEMBLY/4. DRIVE SHAFT ASSEMBLY (R.H.)**

Refer to 2-44, 52.

**5. REMOVAL OF INNER SHAFT**

Attach the special tools to the flange of the shaft, and drive the inner shaft out from the front differential carrier.

**Caution**

1. Being careful not to scratch or scar the shock absorber with the special tool, remove the lower mounting bolts of the shock absorber, and compress the shock absorber as much as possible.
2. When pulling the inner shaft out from the front differential carrier, be careful that the spline part of the inner shaft does not damage the oil seal.

**INSPECTION**

N02RCAA

- Check the inner shaft for bend.
- Check the bearing for wear or discoloration.
- Check the housing tube for cracks.
- Check the dust seal for cracks or damage.

**SERVICE POINTS OF INSTALLATION**

N02DAB

**5. INSTALLATION OF INNER SHAFT**

Drive the inner shaft into the front differential carrier by using the special tools.

**Caution**


1. Replace the circlip which is attached to the inner shaft spline part with a new one.
2. Be careful not to damage the lip of the dust seal and oil seal.

**4. INSTALLATION OF DRIVE SHAFT ASSEMBLY (R.H.)/2. FRONT HUB AND KNUCKLE ASSEMBLY**

Refer to 2-44, 52.

DISASSEMBLY AND REASSEMBLY

N02RE--




Disassembly steps

- 1. Inner shaft
- 2. Bearing
- 3. Dust cover
- 4. Housing tube
- 5. Dust seal

11W597

NOTE

- (1) Reverse the disassembly procedures to reassemble.
- (2) ◀▶ : Refer to "Service Points of Disassembly".
- (3) ▶▶ : Refer to "Service Points of Reassembly".
- (4) N : Non-reusable parts




SERVICE POINTS OF DISASSEMBLY


N02RFAB

2. REMOVAL OF BEARING

- (1) Bend the outside periphery of dust cover inward with a hammer.




- (2) After the special tool has been installed as shown, tighten the nut of the special tool until the portion "A" of the special tool touches the bearing outer race.



- (3) Press out the inner shaft from the bearing.


Caution

Do not allow the inner shaft to drop.




**3. REMOVAL OF DUST COVER**

Remove the dust cover from the inner shaft.



**5. REMOVAL OF DUST SEAL**

Remove the dust seal from the housing tube.




**SERVICE POINTS OF REASSEMBLY**

NO2RHAD

**5. INSTALLATION OF DUST SEAL**

- (1) Press-fit the new dust seal into the housing tube by using the special tools, until it is flush with the housing tube end face.
- (2) Apply the specified grease to the dust seal lip.


**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**



**3. INSTALLATION OF DUST COVER**

Using a steel pipe, force a new dust cover onto the inner shaft.

| Steel pipe       | mm (in.)  |
|------------------|-----------|
| Overall length   | 50 (1.97) |
| Outside diameter | 75 (2.95) |
| Wall thickness   | 4 (.16)   |



**NOTE**

After the dust cover has been installed, apply specified grease to the inside of the dust cover.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**


**2. INSTALLATION OF BEARING**

Using the special tool, force the bearing onto the inner shaft.

FRONT DIFFERENTIAL MOUNTING

REMOVAL AND INSTALLATION

N02UA--



12W554


Removal steps

- 1. Under cover
- ◄◄ ◄◄ 2. Drive shaft
- ◄◄ ◄◄ 3. Circlip
- ◄◄ ◄◄ 4. Inner shaft
- 5. Circlip
- 6. Self-locking nut
- 7. Differential mounting rubber A
- 8. Differential mounting rubber B
- ◄◄ 9. Differential mounting bracket (L.H.)
- 10. Self-locking nut
- 11. Differential mounting rubber A
- 12. Differential mounting rubber B

- ◄◄ 13. Differential mounting bracket (R.H.)
- 14. Self-locking nut
- 15. Differential mounting rubber C
- 16. Differential mounting rubber D

NOTE

- (1) Reverse the removal procedures to reinstall.
- (2) ◄◄ : Refer to "Service Points of Removal".
- (3) ◄◄ : Refer to "Service Points of Installation".
- (4) N : Non-reusable parts

**SERVICE POINTS OF REMOVAL**

N02UBAB

**2. REMOVAL OF DRIVE SHAFT**

Refer to P.2-52.

**4. REMOVAL OF INNER SHAFT**

Attach the special tools to the flange of the shaft, and drive the inner shaft out from the front differential carrier.

**Caution**

1. Being careful not to scratch or scar the shock absorber with the special tool, remove the lower mounting bolts of the shock absorber, and compress the shock absorber as much as possible.
2. When pulling the inner shaft out from the front differential carrier, be careful that the spline part of the inner shaft does not damage the oil seal.

**9. REMOVAL OF DIFFERENTIAL MOUNTING BRACKET (L.H.) / 13. DIFFERENTIAL MOUNTING BRACKET (R.H.)**

While supporting the differential carrier with a jack, remove the differential mounting bracket.

**NOTE**

Support the differential carrier with a jack until installing the differential mounting bracket.

**INSPECTION**

N02UCAA

- Check the differential mounting bracket for deformation and damage.
- Check the bracket for deformation and damage.
- Check the differential mounting rubber for cracks and damage.

**SERVICE POINTS OF INSTALLATION**

N02UDAA

**4. INSTALLATION INNER SHAFT**


Drive the inner shaft into the front differential carrier by using the special tools.

**Caution**

Be careful not to damage the lip of the dust seal and oil seal.


**2. INSTALLATION OF DRIVE SHAFT**

Refer to P.2-52.



# DIFFERENTIAL CARRIER REMOVAL AND INSTALLATION

N02VA--



11W612

### Removal steps

- 1. Under cover
- ◄◄ ◄◄ 2. Drive shaft
- ◄◄ ◄◄ 3. Circlip
- ◄◄ ◄◄ 4. Inner shaft
- ◄◄ 5. Circlip
- ◄◄ 6. Front propeller shaft
- ◄◄ 7. Self-locking nut
- ◄◄ 8. Differential mounting bracket (L.H.)
- 9. Self-locking nut
- 10. Front suspension crossmember and front differential carrier assembly
- 11. Self-locking nut
- 12. Front suspension crossmember
- 13. Differential mounting bracket (R.H.)
- 14. Housing tube
- 15. Front differential carrier assembly

### Pre-removal Operation

- Draining of Gear Oil (Refer to P.2-16.)

### Post-installation Operation

- Supplying Gear Oil (Refer to P.2-16.)

### NOTE


- (1) Reverse the removal procedures to reinstall.
- (2) ◄◄ : Refer to "Service Points of Removal".
- (3) ◄◄ : Refer to "Service Points of Installation".
- (4) N : Non-reusable parts

**SERVICE POINTS OF REMOVAL**

N02VBAB

**2. REMOVAL OF KNUCKLE AND DRIVE SHAFT ASSEMBLY**


Refer to P.2-44, 52.

**4. REMOVAL OF INNER SHAFT**

Attach the special tools to the flange of the shaft, and pull the inner shaft out from the front differential carrier.

**Caution**

1. Being careful not to scratch or scar the shock absorber with the special tool, remove the lower mounting bolts of the shock absorber, and compress the shock absorber as much as possible.
2. When pulling the inner shaft out from the front differential carrier, be careful that the spline part of the inner shaft does not damage the oil seal.


**6. REMOVAL OF FRONT PROPELLER SHAFT**

Make the mating marks on the flange yoke and the differential companion flange.

Detach the propeller shaft from the front differential carrier assembly.


**8. REMOVAL OF DIFFERENTIAL MOUNTING BRACKET (L.H.)**

While supporting the differential carrier with a jack, remove the differential mounting bracket.

**INSPECTION BEFORE DISASSEMBLY**

N02VCAA

Remove the cover and gasket. Hold the working base in a vice, and install the differential carrier assembly to the working base.

**FINAL DRIVE GEAR BACKLASH**

Check the final drive gear backlash by following the steps below.


- (1) With the drive pinion locked in place, measure the final drive gear backlash with a dial indicator on the drive gear.

**NOTE**

Measure at four points or more on the circumference of the drive gear.

**Standard value : 0.11–0.16 mm (.0043–.0063 in.)**

- (2) If the backlash is not within the standard value, adjust it by using the side bearing adjustment spacers.


**DRIVE GEAR RUNOUT**

Check the drive gear runout by following the steps below.

- (1) Measure the drive gear runout at the shoulder on the reverse side of the drive gear.

**Limit : 0.05 mm (.0020 in.)**

- (2) If the runout exceeds the limit, check for improper tightening of the drive gear and differential case.

**DIFFERENTIAL GEAR BACKLASH**

Check the differential gear backlash by following the steps below.

- (1) While locking the side gear with the wedge, measure the differential gear backlash with a dial indicator on the pinion gear.


**NOTE**

The measurement should be made for both pinion gears individually.

**Standard value : 0–0.076 mm (0–.0030 in.)**


**Limit : 0.2 mm (.0079 in.)**

- (2) If the backlash exceeds the limit, adjust by using the side gear thrust spacers.

**FINAL DRIVE GEAR TOOTH CONTACT**

Check the tooth contact of the final drive gear by following the steps below.

- (1) Apply a thin, uniform coat of machine blue to both surfaces of the drive gear teeth.



- (2) Insert the brass between the differential carrier and the differential case, and then rotate the companion flange by hand (once in the normal direction, and then once in the reverse direction) while applying a load to the drive gear so that the revolution torque [approximately 2.5 to 3.0 Nm (1.8 to 2.2 ft.lbs.)] is applied to the drive pinion.

**Caution**

**If the drive gear is rotated too much, the tooth contact pattern will become unclear and difficult to check.**

- (3) Check the tooth contact condition of the drive gear and drive pinion.

**NOTE**


1. Checking the tooth contact pattern is the way to confirm that the adjustments of the pinion height and backlash have been done properly.
2. Continue to adjust the pinion height and backlash until the tooth contact pattern resembles the standard pattern.
3. If, even after adjustments have been made, the correct tooth contact pattern cannot be obtained, it means that the drive gear and the drive pinion have become worn beyond the allowable limit; replace the gear set.

**Caution**

**If either the drive gear or the drive pinion is to be replaced, be sure to replace both gears as a set.**

**Standard tooth contact pattern**



- 1 Toe
- 2 Drive-side
- 3 Heel
- 4 Coast-side



Problem

Solution



**Tooth contact pattern resulting from excessive pinion height**



The drive pinion is positioned too far from the center of the drive gear.

Increase the thickness of the pinion height adjusting shim, and position the drive pinion closer to the center of the drive gear. Also, for backlash adjustment, position the drive gear farther from the drive pinion.


**Tooth contact pattern resulting from improper pinion height**



The drive pinion is positioned too close to the center of the drive gear.

Decrease the thickness of the pinion height adjusting shim, and position the drive pinion farther from the center of the drive gear. Also, for backlash adjustment, position the drive gear closer to the drive pinion.

11S642



**SERVICE POINTS OF INSTALLATION**

NO2VDAB

**4. INSTALLATION OF INNER SHAFT**

Drive the inner shaft into the front differential carrier by using the special tools.

**Caution**


**Be careful not to damage the lip of the dust seal and oil seal.**

**2. INSTALLATION OF DRIVE SHAFT**

Refer to P.2-52.

DISASSEMBLY

N02VE--



11W571

**Inspection before Disassembly**


- Final Drive Gear Backlash
- Drive Gear Backlash
- Differential Gear Backlash
- Final Drive Gear Tooth Contact

} Refer to P.2-69-72.

**Disassembly steps**

- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>1. Cover</li> <li>2. Gasket</li> <li>3. Bearing caps</li> <li>↔ 4. Differential case assembly</li> <li>5. Side bearing adjusting spacers</li> <li>6. Side bearing outer races</li> <li>↔ 7. Side bearing inner races</li> <li>8. Bolts (10)</li> <li>↔ 9. Drive gear</li> <li>↔ 10. Lock pin</li> <li>11. Pinion shaft</li> <li>12. Pinion gears</li> <li>13. Pinion washers</li> <li>14. Side gears</li> <li>15. Side gear thrust spacers</li> <li>16. Differential case</li> <li>↔ 17. Companion flange self-locking nut</li> <li>18. Washer</li> <li>↔ 19. Drive pinion assembly</li> <li>↔ 20. Drive pinion front bearing inner race</li> </ul> | <ul style="list-style-type: none"> <li>21. Drive pinion front shim (for pinion height adjustment)</li> <li>22. Drive pinion</li> <li>23. Companion flange</li> <li>24. Drive pinion spacer</li> <li>25. Drive pinion rear shim (for preload adjustment)</li> <li>26. Oil seal</li> <li>27. Drive pinion rear bearing inner race</li> <li>↔ 28. Drive pinion rear bearing outer race</li> <li>↔ 29. Drive pinion front bearing outer race</li> <li>30. Oil seals</li> <li>31. Gear carrier</li> <li>32. Vent plug</li> </ul> |
|--|---|

NOTE  
 (1) ↔ : Refer to "Service Points of Disassembly".  
 (2) [N] : Non-reusable parts

**SERVICE POINTS OF DISASSEMBLY**

N02VFAA

**4. REMOVAL OF DIFFERENTIAL CASE ASSEMBLY**


Take out the differential case assembly with a hammer handle.

**Caution**


When taking out the differential case assembly, be careful not to drop and damage the side bearing outer races.

**NOTE**


Keep the right and left side bearings and side bearing adjusting spacers separate, so that they do not become mixed at the time of reassembly.

**7. REMOVAL OF SIDE BEARING INNER RACES**

Pull out the side bearing inner races by using the special tools.

**9. REMOVAL OF DRIVE GEAR**


- (1) Make the mating marks to the differential case and the drive gear.
- (2) Loosen the drive gear attaching bolts in diagonal sequence to remove the drive gear.

**10. REMOVAL OF LOCK PIN**


Drive out the lock pin with a punch.

**NOTE**

The removed side gears and side gear thrust spacers, left and right, should be retained for reassembly.

**17. REMOVAL OF COMPANION FLANGE SELF-LOCKING NUT**

Use the special tool to hold the companion flange and remove the companion flange self-locking nut.




**19. REMOVAL OF DRIVE PINION ASSEMBLY**

- (1) Make mating marks on the drive pinion and companion flange.

**Caution**


The mating mark made on the companion flange must not be on the coupling surface of the flange yoke and the front propeller shaft.

- (2) Drive out the drive pinion together with the drive pinion spacer and drive pinion shims.




**20. REMOVAL OF DRIVE PINION FRONT BEARING INNER RACE**

Pull out the drive pinion front bearing inner race by using the special tools.



**28. REMOVAL OF DRIVE PINION REAR BEARING OUTER RACE**

Drive out the drive pinion rear bearing outer race from the gear carrier by using the brass rod



**29. REMOVAL OF DRIVE PINION FRONT BEARING OUTER RACE**


Drive out the drive pinion front bearing outer race from the gear carrier by using the brass rod.

**INSPECTION**


N02VGAA

- Check the companion flange for wear or damage.
- Check the oil seal for wear or deterioration.
- Check the bearings for wear or discoloration.
- Check the gear carrier for cracks.
- Check the drive pinion and ring gear for wear or cracks.
- Check the side gears, pinion gears and pinion shaft for wear or damage.
- Check the side gear spline for wear or damage.

REASSEMBLY




11W571



Reassembly steps

1. Vent plug
2. Gear carrier
- ◆◆ 3. Oil seals
- ◆◆ 4. Drive pinion front bearing outer race
- ◆◆ 5. Drive pinion rear bearing outer race
- ◆◆ Adjustment of pinion height
6. Drive pinion
7. Drive pinion front shim (for pinion height adjustment)
8. Drive pinion front bearing inner race
- ◆◆ Adjustment of drive pinion preload
9. Drive pinion rear bearing inner race
10. Oil seal
11. Drive pinion rear shim (for preload adjustment)
12. Drive pinion spacer
13. Drive pinion assembly
14. Companion flange
15. Washer
16. Companion flange self-locking nut
17. Differential case
18. Side gear thrust spacers
19. Side gears
20. Pinion washers
21. Pinion gears
- ◆◆ Adjustment of differential gear backlash
22. Pinion shaft
- ◆◆ 23. Lock pin
- ◆◆ 24. Drive gear
25. Bolts (10)
- ◆◆ 26. Side bearing inner races
27. Side bearing outer races
- ◆◆ Adjustment of final drive gear backlash
28. Side bearing adjusting spacers
29. Differential case assembly
30. Bearing caps
- ◆◆ 31. Gasket
32. Cover

NOTE  
 (1) ◆◆ : Refer to "Service Points of Reassembly".  
 (2) [N] : Non-reusable parts




**SERVICE POINTS OF REASSEMBLY**

N02VIAB

**3. INSTALLATION OF OIL SEALS**

Install the oil seal with the special tool and apply a thin coat of specified grease to the lip of the oil seal.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**




**4. INSTALLATION OF DRIVE PINION FRONT BEARING OUTER RACE**

Press-fit the drive pinion front bearing outer races into the gear carrier by using the special tools.

**NOTE**

Perform press-fitting carefully so as not to tilt the outer race.




**5. INSTALLATION OF DRIVE PINION REAR BEARING OUTER RACE**

Press-fit the drive pinion rear bearing outer races into the gear carrier by using the special tools.

**NOTE**

Perform press-fitting carefully so as not to tilt the outer race.




**● ADJUSTMENT OF PINION HEIGHT**

Adjustment the drive pinion height by the following procedures:



- (1) Install special tools and drive pinion front and rear bearing inner races to the gear carrier in the sequence shown in the illustration.
- (2) Tighten the handle of the special tool until the standard value of drive pinion rotation torque is obtained.
- (3) Measure the drive pinion rotation torque (without the oil seal) by using the special tools.

**Standard value : 0.4–0.5 Nm (3.5–4.3 in. lbs.)**



## NOTE

1. Gradually tighten the handle of the special tool while checking the drive pinion preload.
2. Because one rotation can't be made when the special tool is in contact with the gear carrier, move it a few times and, after seating the bearing, measure the rotation torque.



- (4) Position the special tool in the side bearing seat of the gear carrier, and then select a drive pinion front shim of a thickness which corresponds to the gap between the special tools.

## NOTE

1. Be sure to clean the side bearing seat thoroughly. When positioning the special tool, be sure that the cut-out sections of the special tool are in the position shown in the illustration, and also confirm that the special tool is in close contact with the side bearing seat.
2. When selecting the drive pinion front shims, keep the number of shims to a minimum.
- (5) Fit the selected drive pinion front shim(s) to the drive pinion, and press-fit the drive pinion front bearing inner race by using the special tool.

### ● ADJUSTMENT OF DRIVE PINION PRELOAD

Adjust the drive pinion turning torque by using the following procedure:


#### Without Oil Seal


- (1) Insert the drive pinion into the gear carrier, and then install, from the front side of the carrier, the drive pinion spacer, the drive pinion rear shim; the drive pinion rear bearing inner race, and the companion flange in that order.

## NOTE

Do not install the oil seal.

- (2) Tighten the companion flange to the specified torque by using the special tool.





- (3) Measure the drive pinion rotation torque (without the oil seal).


**Standard value : 0.4–0.5 Nm (3.5-4.3 in.lbs.)**

- (4) If the drive pinion rotation torque is not within the range of the standard value, adjust the preload by replacing the drive pinion rear shim(s) or the drive pinion spacer.

**NOTE**

When selecting the drive pinion rear shims, if the number of shims is large, reduce the number of shims to a minimum by selecting the drive pinion spacers.


- (5) Remove the companion flange and drive pinion once again.



**With Oil Seal**


- (1) After setting the drive pinion rear bearing inner race, drive the oil seal into the gear carrier front lip by using the special tool.  
 (2) Apply the specified grease to the oil seal lip.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**




- (3) Apply a thin coat of specified grease to the companion flange contacting surface of the washer before installing drive pinion assembly.

**Specified grease : Multipurpose grease SAE J310, NLGI No. 2**



- (4) Install the drive pinion assembly and companion flange with mating marks properly aligned, and tighten the companion flange self-locking nut to the specified torque by using the special tools.




11Y223

- (5) Measure the drive pinion rotation torque (with oil seal) to verify that the drive pinion preload complies with the standard value.

**Standard value : 0.6–0.7 Nm (5.2–6.1 in.lbs.)**

- (6) If the measured value is not within the standard value range, check for faulty installation of the oil seal or faulty tightening of the self-locking nut.




11F043

● **ADJUSTMENT OF DIFFERENTIAL GEAR BACKLASH**

- (1) Assemble the side gears, side gear thrust spacers, pinion gears, and pinion washers into the differential case.  
 (2) Temporarily install the pinion shaft.

**NOTE**

Do not drive in the lock pin yet.




11Y109

- (3) Insert a wedge between the side gear and the pinion shaft to lock the side gear.  
 (4) Measure the differential gear backlash with a dial indicator on the pinion gear.

**Standard value : 0–0.076 mm (0–.0030 in.)**

**Limit : 0.2 mm (.008 in.)**




- (5) If the differential gear backlash exceeds the limit, adjust the backlash by installing thicker side gear thrust spacers.  
 (6) Measure the differential gear backlash once again, and confirm that it is within the limit.  
 If adjustment is not possible, replace the side gears and pinion gears as a set.



11Y061

**23. INSTALLATION OF LOCK PIN**

- (1) Align the pinion shaft lock pin hole with the differential case lock pin hole, and drive in the lock pin.  
 (2) Stake the lock pin with a punch at two points.



## 24. INSTALLATION OF DRIVE GEAR

- (1) Clean the drive gear attaching bolts.
- (2) Remove the adhesive adhered to the threaded holes of the drive gear by turning the tap tool (M10 x 1.25), and then clean the threaded holes by applying compressed air.

- (3) Apply the specified adhesive to the threaded holes of the drive gear.

**Specified adhesive : 3M Adhesive stud locking 4170 or equivalent**

- (4) Install the drive gear onto the differential case with the mating marks properly aligned. Be sure to tighten the bolts to the specified torque in a diagonal sequence.

## 26. INSTALLATION OF SIDE BEARING INNER RACES

Press-fit the side bearing inner races to the differential case by using the special tool.


## ● ADJUSTMENT OF FINAL DRIVE GEAR BACKLASH






- (1) Install the side bearing adjusting spacers, which are thinner than those removed, to the side bearing outer races, and then mount the differential case assembly into the gear carrier.

### NOTE

Select side bearing adjusting spacers with the same thickness for both the drive pinion side and the drive gear side.

- (2) Push the differential case assembly to one side, and measure the clearance between the gear carrier and the side bearing adjusting spacer with a feeler gauge.





(3) Measure the thickness of the side bearing adjusting spacers on one side, select two pairs of spacers which correspond to that thickness plus one half of the clearance plus 0.05 mm (.002 in.), and then install one pair each to the drive pinion side and the drive gear side.

(4) Install the side bearing adjusting spacers and differential case assembly, as shown in the illustration, to the gear carrier.

(5) Tap the side bearing adjusting spacers with the brass bar to fit them to the side bearing outer race.




(6) Align the mating marks on the gear carrier and the bearing cap, and then tighten the bearing cap.

(7) With the drive pinion locked in place, measure the final drive gear backlash with a dial indicator on the drive gear.

**NOTE**

Measure at four points or more on the circumference of the drive gear.

**Standard value : 0.11–0.16 mm (.0043–.0063 in.)**



(8) Change the side bearing adjusting spacers as illustrated, and then adjust the final drive gear backlash between the drive gear and the drive pinion.

**NOTE**

When increasing the number of side bearing adjusting spacers, use the same number for each, and as few as possible.

(9) Check the drive gear and drive pinion for tooth contact. If poor contact is evident, make adjustment. (Refer to P.2-71)

(10) Measure the drive gear runout at the shoulder on the reverse side of the drive gear.

**Limit : 0.05 mm (.0020 in.)**

(11) If the drive gear runout exceeds the limit, reinstall by changing the phase of the drive gear and differential case, and remeasure.

**31. APPLICATION OF SEALANT TO GASKET**

Apply the specified sealant to both sides of the gasket and install the differential cover to the differential carrier.

**Specified sealant : 3M ART Part No. 8661 or No. 8663, or equivalent**