

# WHEELS AND TIRES

## CONTENTS

N22AA--

<b>GENERAL INFORMATION</b> .....	<b>2</b>	<b>TROUBLESHOOTING</b> .....	<b>3</b>
<b>SERVICE ADJUSTMENT PROCEDURES</b> .....	<b>4</b>	Bald Spots	
Checking Tire Inflation Pressure .....	4	Cracked Treads	
Checking Tire Wear .....	4	Feathered Edge	
Checking Wheel Runout .....	4	Rapid Wear at Center	
<b>SPARE TIRE CARRIER</b> .....	<b>6</b>	Rapid Wear at Shoulders	
<b>SPECIFICATIONS</b> .....	<b>2</b>	Scalloped Wear	
General Specifications .....	2	Wear on One Side	
Sealant and Adhesive .....	2	<b>WHEELS AND TIRES</b> .....	<b>4</b>
Service Specifications .....	2		
Torque Specifications .....	2		

**GENERAL INFORMATION**

N22BAAD

All models are equipped with tubeless radial tires and styled wheels.

**SPECIFICATIONS****GENERAL SPECIFICATIONS**

N22CA--

Items	Specifications
Wheel	
Tire size	P225/75R-15
Wheel type	Steel type
Wheel size	6JJ x 15
Amount of wheel offset   mm (in.)	22 (.87)
Tire inflation pressure   kPa (psi)	
Front wheels	180 (26)
Rear wheels	240 (34), *180 (26)

**NOTE**

\*Minimum tire inflation pressure for improving ride comfort when driving with no cargo.

**SERVICE SPECIFICATIONS**

N22CB--

Items	Specifications
Limit	
Wheel runout	
Radial   mm (in.)	3 (.12)
Lateral   mm (in.)	3 (.12)
Tread depth of tire   mm (in.)	1.6 (.06)

**TORQUE SPECIFICATIONS**

N22CC--

Items	Nm	ft.lbs.
Hub nuts for steel wheel	100–120	72–87
Spare tire bracket to body	8–10	6–7













**SEALANT AND ADHESIVE**



N22CD--

Item	Specified sealant and adhesive	Quantity
Spare tire bracket mounting bolts	3M ART Part No. 8634 or equivalent	As required

**TROUBLESHOOTING**

N22EA--

Symptom	Probable cause	Remedy	Reference page
Rapid wear at shoulders 	Under-inflation or lack of rotation 	Adjust the tire pressure	22-2
Rapid wear at center 	Over-inflation or lack of rotation 		
Cracked treads 	Under-inflation		
Wear on one side 	Excessive camber 	Inspect the camber	2-15
Feathered edge 	Incorrect toe 	Adjust the toe-in	2-15
Bald spots 	Unbalanced wheel 	Adjust the imbalanced wheels	–
Scalloped wear 	Lack of rotation of tires or worn or out-of-alignment suspension	Rotate the tires Inspect the front suspension alignment	22-6, 2-15



**SERVICE ADJUSTMENT PROCEDURES**

**CHECKING TIRE INFLATION PRESSURE** N22FDAA

Check the inflation pressure of the tires.  
If it is not within the standard value, make the necessary adjustment.

**CHECKING TIRE WEAR** N22FBAB

Measure the tread depth of tires

**Limit : 1.6 mm (.06 in.)**

If the remaining tread depth is less than the limit, replace the tire.

**NOTE**

When the tread depth of tires is reduced to 1.6 mm (.06 in.) or less, wear indicators will appear.

**CHECKING WHEEL RUNOUT** N22FCAB


Jack up the vehicle so that the wheels are clear of the floor.  
While slowly turning the wheel, measure wheel runout with a dial indicator.

**Limit : Radial 3.0 mm (.12 in.)  
Lateral 3.0 mm (.12 in.)**

If wheel runout exceeds the limit, replace the wheel.

**WHEELS AND TIRES  
REMOVAL AND INSTALLATION**

N22GA--









**Removal steps**

- ◄► 1. Center cap
- 2. Hub nut
- 3. Center cap holder
- 4. Balance weight
- 5. Steel wheel
- 6. Tire

**NOTE**

- (1) Reverse the removal procedures to reinstall.
- (2) ◄► : Refer to "Service Points of Removal".
- (3) ►► : Refer to "Service Points of Installation".



**SERVICE POINTS OF REMOVAL**

N22GBAB

**1. REMOVAL OF CENTER CAP**

- (1) Using the vehicle equipped tool (wheel cap wrench or wheel nut wrench), remove the center cap.

**Caution**

**Use a piece of cloth or other, similar material to prevent scratching the wheel when the wheel cap wrench or wheel nut wrench is used.**

- (2) For vehicles with manual free-wheel hubs, remove the wheel caps as described below.

- ① Move the wheel cap wrench or wheel nut wrench as shown in the figure so as to slightly lift the wheel cap so that there is a space. Insert a screwdriver in this space.

- ② Remove the wheel cap wrench or wheel nut wrench and use it at the opposite side.

- ③ Move each tool as shown in the figure so as to remove the wheel cap.

**SERVICE POINTS OF INSTALLATION**

N22GDAA


**3. INSTALLATION OF CENTER CAP HOLDER**

**NOTE**

Note that the center cap attaching metal fittings for the front and rear wheels are different in shape.

- (1) Align any of the guides (three projections) inside the fitting with a bolt position, and install the fitting on the hub, while using care to make sure that the cut ends are not opened. (Front wheel)

- (2) Align any of the guides (three projections) inside the fitting with the position of a wheel attaching hole (B) and install the fitting properly to the disc wheel from inside the disc wheel. (Rear wheel)

**WHEEL ROTATION**

N22GE--

Rotate the wheels in order to equalize tire wear in the patterns illustrated.


**TIRE CHAINS AND SNOW TIRES**

N22GGAB

1. Use tire chains only on rear wheels. Do not use tire chain on front wheels.
2. When using snow tires, use them on all four wheels for maneuverability and safety.

**SPARE TIRE CARRIER****REMOVAL AND INSTALLATION**

N22HA--



8-10 Nm  
6-7 ft.lbs.

11W600

**Removal steps**

1. Hub nut
2. Spare tire
- ◆◆ 3. Spare tire bracket

**NOTE**

- (1) Reverse the removal procedures to reinstall.
- (2) ◆◆ : Refer to "Service Points of Installation".

**SERVICE POINTS OF INSTALLATION**

N22HDAC

**3. APPLICATION OF SEALANT TO SPARE TIRE BRACKET**

Apply a coat of the specified sealant around the spare tire bracket mounting bolts.

**Specified sealant : 3M ART Part No. 8634 or equivalent**